Original		Replacement	
POWER	Power		Power
ECO	Eco	ECO 3D	3D
1	Quick Select 1	1	1
2	Quick Select 2	2	2
3	Quick Select 3	3	3
4	Quick Select 4	4	4
	Up		Up
ENTER	Enter	OK	Ok
	Down		Down
	Right		Right
	Left		Left
VOLUME	Vol +	VOL +	Vol +
VOLUME	Vol -	VOL −	Vol -
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options

Original		Replacement	
	I <<		I <<
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
MUTE	Mute	MUTE	Mute
CHANNEL +	CH+	CH +	Ch +
CHANNEL −	CH-	CH −	Ch -
SEARCH	Search	SEARCH TV/R	TV/R
RESTORER	Restorer	CLEAR EXIT	Exit
CH LEVEL	CH Level	APP MEDIA	Media
MODE	Mode	AD SUBT	Subt
TV AUDIO	Tv Audio	SOUND DUAL	Dual
Bluetooth	Bluetooth	HOME SMART	Smart
MEMORY	Memory	TIMER AV	AV
CBL/SAT	CBL/Sat	5	5
DVD/ Blu-ray	DVD/Bluray	6	6
FM	FM	7	7

https://mandis.tv/en/Denon/1360584-replacement-remote-control-for-Denon-RC1196/0/0/0

Original		Replacement		Original	Replacement
Blu-ray	Blu-ray	8	8		
GAME	Game	9	9		
AM	AM	GUIDE	Guide		
MEDIA PLAYER	Media Player	0	0		
USB	USB	PRE-CH	Pre Ch		
►	Sound Mode >	B	Green		
◄	< Sound Mode	A	Red		
+	Audio Delay+	D	Blue		
–	Audio Delay-	C	Yellow		
TUNE +	Tune+	»	>>		
TUNE –	Tune-	«	<<		
SLEEP	Sleep	SLEEP	Sleep		