| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| MUTE | Mute | MUTE | Mute |
| DVB/Analogue | DVB/Analogue | HOME SMART | Smart |
| AV | AV | TIMER AV | AV |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| ABC 1 | 1 | 1 | 1 |
| DEF 2 | 2 | 2 | 2 |
| GHI 3 | 3 | 3 | 3 |
| JKL 4 | 4 | 4 | 4 |
| MNO 5 | 5 | 5 | 5 |
| PQR 6 | 6 | 6 | 6 |
| STU 7 | 7 | 7 | 7 |
| VWX 8 | 8 | 8 | 8 |
| YZ&. 9 | 9 | 9 | 9 |
| +-*/! 0 | 0 | 0 | 0 |
| S.EFFECT | S. Effect | APP MEDIA | Media |
| | ▼/ O( / I / I I | SHIFT + SOUND DUAL | Shift + Dual |

| Original | | Replacement | |
|---|---|---|---|
| VOL ▲ | Vol + | + VOL | Vol + |
| VOL ▼ | Vol - | VOL − | Vol - |
| PR/PAGE ▲ | PR/Page+ | + CH | Ch + |
| PR/PAGE ▼ | PR/Page- | CH − | Ch - |
| | Up/ [ ≡▲] | | Up |
| | Down/ [ ≡▼] | | Down |
| | Right | | Right |
| | Left | | Left |
| SELECT OK | OK/Select | OK | Ok |
| GUIDE | Guide | -/-- GUIDE | Guide |
| SUBTITLE | Subtitle | AD SUBT | Subt |
| LANGUAGE | Language | SOUND DUAL | Dual |
| FAVOURITE | Favourite | FAV PRE-CH | Pre Ch |
| PREV PR | Prev PR | RETURN BACK | Back |
| MENU M | Menu | TOP MENU MENU | Menu |
| ASPECT | Aspect | ECO 3D | 3D |
| NORMAL | Normal | SETTINGS OPT | Options |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| RECALL [i] / Recall | DISPLAY INFO Info | | |
| CANCEL/EXIT Cancel / Exit | CLEAR EXIT Exit | | |
| Red | A Red | | |
| Green | B Green | | |
| Yellow | C Yellow | | |
| Blue | D Blue | | |
| TEXT [≡] / Text | REPEAT TEXT Text | | |
| REVEAL [≡?] / Reveal | SEARCH TV/R TV/R | | |
| T.CANCEL [≡x] / T. Cancel | ZOOM ⏏ Eject | | |
| SIZE [≡↕] / Size | PICTURE FORMAT Format | | |
| SUBCODE [≡o] / Subcode | E-MANUAL D.MENU D. Menu | | |
| HOLD [≡+] / Hold | SHIFT + SEARCH TV/R Shift + TV/R | | |
| INDEX [≡i] / Index | DISC NAV LIST List | | |
| GAME Game | SHIFT + HOME SMART Shift + Smart | | |
| | | | |
| | | | |
| | | | |