Original	Replacement	Original	Replacement
Power	Power	0	0
Mute	Mute	-/--/EXIT	-/-- Guide
Up	Up	-/--/EXIT	Exit
Down	Down	P<P/SWAP	P<P/Swap Pre Ch
Right	Right	V+	Vol +
Left	Left	V-	Vol -
OK/SELECT	OK/Select Ok	P+	Ch +
M	Menu	P-	Ch -
1/ABC	1 1	PP	PP Eject
2/DEF	2 2	I-II	I-II Dual
3/GHI	3 3	TV/DTV	Tv/DTV TV/R
4/JKL	4 4	[≡]	Text
5/MNO	5 5	[≡O]	Options
6/PQR	6 6	AV/SOURCE	AV/Source AV
7/STU	7 7	[≡+] / [X]	Format
8/VWX	8 8	[≡X] / [■■]	3D
9/YZ	9 9	[.≡] / [■]	Subt

Original		Replacement		Original	Replacement
	[≡♦]		Medi a		
	[≡?]		Back		
	[≡i]		I nf o		
	Red/ [+] / Wi de/ ↑		Red		
	Gr een/ ↓		Gr een		
	Yel l ow		Yel l ow		
	Bl ue/ Gui de		Bl ue		
	[i]		D. Menu		