Original	Replacement	Original	Replacement
On/Off	Power		
Mute	Mute / Dimmer		
Menu Up	Up		
Menu Left	Left		
Menu Right	Right		
Menu Down	Down		
Volume+	Vol+		
Chan.Up	CH+ / Page+		
Volume-	Vol-		
Chan.Down	CH- / Page-		

Original	Replacement	Original	Replacement
Power ON/Off	Power	Tape 1 Rew	I<< / Preset-
Mute	Mute / Dimmer	Tape 1 Play	OK
Tape 1 Stop	Stop / Hold	Tape 1 F.FWD	>>I / Preset+
Tape 2 Pre./eq	D.Menu / Top		
Input/Source	AV / Input / RDS		
CD/Theater	Menu / Home		
CD Play	Play / Slow		
CD F.FWD	>> / Tune+		
CD Pause	Pause / Step / Freeze		
CD Rewind	<< / Tune-		
Funct./Direct	Exit / Cancel / Clear		
Volume+	Vol+		
Next/Prog+	CH+ / Page+		
Volume-	Vol-		
Tape 1 Hall/Ats	Display / Media		
Prev./Prog-	CH- / Page-		
Program	TV/Radio / Program		