Original	Replacement
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
8	8
5	5
6	6
7	7
9	9
0	0
Source	AV
Recall	Pre Ch
Menu	Menu
Exit	Exit
[<>]	Format

Original	Replacement
[ ]	3D
OK	Ok
Up	Up
P+	Ch +
P-	Ch -
Down	Down
Right	Right
Vol +	Vol +
Left	Left
Vol -	Vol -
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
[i +]	Info
Swap	Sleep
O) I / I I	Dual

Original		Replacement		Original	Replacement
	[≡?]	GUIDE	Guide		
	[▼]	SMART	Smart		
	[■] / [I I]	OPT	Options		
	[≡i]	MEDIA	Media		
	[≡]	TEXT	Text		
	[≡o]	SUBT	Subt		
	[O] / [≡x]	TV/R	TV/R		
	[≡♦]	ZOOM	Eject		
	[≡+]	SHIFT + 3D	Shift + 3D		