Mandis shop

# JVC HR-D300

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Power | | Power | | |
| | TV PR- | CH PAGE | CH- / Page- | | |
| | PR- | | Left | | |
| | TV P- | | Down | | |
| | TV PR+ | CH PAGE | CH+ / Page+ | | |
| | PR+ | | Right | | |
| | TV P+ | | Up | | |
| | << | TUNE- | << / Tune- | | |
| | Play | SLOW | Play / Slow | | |
| | >> | TUNE+ | >> / Tune+ | | |
| | Rec | REC MODE | Rec / Rec Mode | | |
| | Stop | HOLD | Stop / Hold | | |
| | Pause | STEP-FREEZE | Pause / Step / Freeze | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

https://mandisremotes.com/en/JVC/1065143-95721-replacement-remote-control-for-JVC-HR-D300.html