Original	Replacement	Original	Replacement
Power	Power	Music/Photo/Cam	3D
Mute	Mute	EPG	Guide
Tv/Radio	TV/R	Vol +	Vol +
FAV	Pre Ch	Vol -	Vol -
World/Internet	Smart	CH+	Ch +
1	1	CH-	Ch -
2	2	Exit	Exit
3	3	Info	Info
4	4	Back	Back
5	5	Menu	Menu
6	6	OK	Ok
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
LIB	List	Stop	Stop
P:P	AV	Play	Play

Original		Replacement		Original		Replacement	
	Rec	REC MODE	Rec				
	Pause		Pause				
	>>		>>				
	<<		<<				
TEXT	Text	REPEAT TEXT	Text				
SUBT.	Subt.	AD SUBT	Subt				
AUDIO	Audio	SOUND DUAL	Dual				
OPT	OPT	SETTINGS OPT	Options				
	Red	A	Red				
	Green	B	Green				
	Yellow	C	Yellow				
	Blue	D	Blue				