Mandis shop

LG AKB73655901

Original		Replacement		Original		Replacement	
	Power		Power				
BACK	Back	RETURN BACK	Back				
HOME	Home	HOME SMART	Smart				
	Up		Up				
	Down		Down				
	Left		Left				
	Right		Right				
	OK	OK	Ok				
INFO/ MENU	Info/Menu	TOP MENU MENU	Menu				
	Play/Pause	PLAY MODE	Play				
	Stop		Stop				
	I<</<<		<<				
	>>I/>>	CH –	Ch -				
	Red	A	Red				
	Green	B	Green				
	Yellow	C	Yellow				
	Blue	D	Blue				

https://mandis.tv/en/LG-AKB73655901-replacement-remote-control-for-LG-AKB73655901.htm