Original	Replacement	Original	Replacement
Power	Power	Vol +	Vol +
Caption	Subtitle / EQ	FAV	Fav / Marker / PC
AV Mode	Text / Goto	CH+	CH+ / Page+
[ ]/Ratio	Display / Media	Vol -	Vol -
Input	AV / Input / RDS	Info	Info / Angle
1	1	CH-	CH- / Page-
2	2	Mute	Mute / Dimmer
3	3	Settings	Setup / OPT /
4	4	Smart	Smart / List
5	5	My APPS	Shift + Green / APP /
6	6	Up	Up
7	7	Left	Left
8	8	OK	OK
9	9	Right	Right
List	Shift + Smart / List	Down	Down
0	0	Back	Back / Return
Flashbk	Zoom / Size	Q. Menu	D. Menu / Top Menu

Original		Replacement	Original	Replacement
EXIT	Exit	CLEAR EXIT CANCEL Exit / Cancel / Clear		
	Red	NETFLIX SEARCH Red / Netflix / Search		
	Green	APP REPEAT Green / APP / Repeat		
	yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM Blue / Prime Video / Random		
	Stop	HOLD Stop / Hold		
	Play	SLOW Play / Slow		
	Pause	STEP-FREEZE Pause / Step / Freeze		
	<<	TUNE- << / Tune-		
	>>	TUNE+ >> / Tune+		
SIMPLINK	Simplink	FORMAT PICTURE Picture / Format		
SLEEP	Sleep	TIMER SLEEP Sleep / Timer		
VD/*	VD/*	SURROUND Eject / Surround		
TV	TV	PROGRAM TV/RADIO TV/Radio /		