Mandis shop

LG AKB73616006

Original		Replacement		Original		Replacement	
Start	Start		Power				
Home	Home		Menu / Home				
Mode	Mode		Setup / OPT /				
Turbo	Turbo		Smart / List				
	Up		Up				
	Left		Left				
Stop OK	Stop/OK	OK	OK				
Stop OK	Stop/OK	HOLD	Stop / Hold				
	Right		Right				
	Down		Down				
Repeat	Repeat	APP REPEAT	Green / APP / Repeat				
My Space	My Space	MEDIA DISPLAY	Display / Media				
	Nothing 1	TV 1	1				
Mute	Mute	DIMMER MUTE	Mute / Dimmer				
	Nothing 2	DVD 2	2				
Diagnosis	Diagnosis	TOP MENU D.MENU	D.Menu / Top				

https://mandisremotes.com/en/LG/1068089-77844-replacement-remote-control-for-LG-AKB73616006.html