| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | P+ | CH+ / Page+ |
| TV | TV/ Radio / | V+ | Vol + |
| Radio | Shift + TV/ Radio / Program | P- | CH- / Page- |
| Subtitle | Subtitle / EQ | V- | Vol - |
| ALT | Smart / List | Red | Red / Netflix / Search |
| ARC | Display / Media | White | Fav / Marker / PC |
| TV Guide | Guide / EPG / -/-- | Green | Green / APP / Repeat |
| Mute | Mute / Dimmer | Blue | Blue / Prime Video / Random |
| Language | Audio / Lang I/II | Yellow | Yellow / YouTube / Repeat |
| PG | Sound / Title | 1 | 1 |
| Info | Info / Angle | 2 | 2 |
| Exit | Exit / Cancel / Clear | 3 | 3 |
| Up | Up | 4 | 4 |
| Left | Left | 5 | 5 |
| OK | OK | 6 | 6 |
| Right | Right | 7 | 7 |
| Down | Down | 8 | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| MENU | Menu | HOME MENU | Menu / Home |
| HELP | Help | GOTO TEXT | Text / Goto |
| 0 _ | 0 | HDMI - SAT 0 | 0 |

| Original | Replacement |
|---|---|
| | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | TV | PROGRAM TV/RADIO | TV/Radio / |
| | Radio | SHIFT + PROGRAM TV/RADIO | Shift + TV/Radio / Program |
| | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| | ALT | LIST SMART | Smart / List |
| | ARC | MEDIA DISPLAY | Display / Media |
| | TV Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Language | LANG I/II AUDIO | Audio / Lang I/II |
| | PG | TITLE SOUND | Sound / Title |
| | Info | ANGLE INFO | Info / Angle |
| | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |

| Original | | Replacement | |
|---|---|---|---|
| | P+ | CH PAGE + | CH+ / Page+ |
| | V+ | VOL + | Vol + |
| | P- | CH PAGE − | CH- / Page- |
| | V- | VOL − | Vol - |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | White | PC FAV MARKER | Fav / Marker / PC |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 1 .,? | 1 | TV 1 | 1 |
| 2 abc | 2 | DVD 2 | 2 |
| 3 def | 3 | CD-STB 3 | 3 |
| 4 ghi | 4 | VIDEO 4 | 4 |
| 5 jkl | 5 | TAPE 5 | 5 |
| 6 mno | 6 | TUNER 6 | 6 |
| 7 pqrs | 7 | AUX-HDD 7 | 7 |
| 8 tuv | 8 | USB 8 | 8 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 9 wxyz | 9 | BLUETOOTH 9 | 9 | | |
| MENU | Menu | HOME MENU | Menu / Home | | |
| HELP | Help | GOTO TEXT | Text / Goto | | |
| 0 _ | 0 | HDMI - SAT 0 | 0 | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | TV | | TV/Radio / |
| | Radio | SHIFT + PROGRAM TV/RADIO | Shift + TV/Radio / Program |
| | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| | ALT | LIST SMART | Smart / List |
| | ARC | MEDIA DISPLAY | Display / Media |
| | TV Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Language | LANG I/II AUDIO | Audio / Lang I/II |
| | PG | TITLE SOUND | Sound / Title |
| | Info | ANGLE INFO | Info / Angle |
| | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |

| Original | | Replacement | |
|---|---|---|---|
| | P+ | CH PAGE + | CH+ / Page+ |
| | V+ | VOL + | Vol + |
| | P- | CH PAGE − | CH- / Page- |
| | V- | VOL − | Vol - |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | White | PC FAV MARKER | Fav / Marker / PC |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 1 .,? | 1 | TV 1 | 1 |
| 2 abc | 2 | DVD 2 | 2 |
| 3 def | 3 | CD-STB 3 | 3 |
| 4 ghi | 4 | VIDEO 4 | 4 |
| 5 jkl | 5 | TAPE 5 | 5 |
| 6 mno | 6 | TUNER 6 | 6 |
| 7 pqrs | 7 | AUX-HDD 7 | 7 |
| 8 tuv | 8 | USB 8 | 8 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 9 wxyz | 9 | BLUETOOTH 9 | 9 | | |
| MENU | Menu | HOME MENU | Menu / Home | | |
| HELP | Help | GOTO TEXT | Text / Goto | | |
| 0 _ | 0 | HDMI - SAT 0 | 0 | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | P+ | CH+ / Page+ |
| TV | TV/ Radio / | V+ | Vol + |
| Radio | Shift + TV/ Radio / Program | P- | CH- / Page- |
| Subtitle | Subtitle / EQ | V- | Vol - |
| ALT | Smart / List | Red | Red / Netflix / Search |
| ARC | Display / Media | White | Fav / Marker / PC |
| TV Guide | Guide / EPG / -/-- | Green | Green / APP / Repeat |
| Mute | Mute / Dimmer | Blue | Blue / Prime Video / Random |
| Language | Audio / Lang I/II | Yellow | Yellow / YouTube / Repeat |
| PG | Sound / Title | 1 | 1 |
| Info | Info / Angle | 2 | 2 |
| Exit | Exit / Cancel / Clear | 3 | 3 |
| Up | Up | 4 | 4 |
| Left | Left | 5 | 5 |
| OK | OK | 6 | 6 |
| Right | Right | 7 | 7 |
| Down | Down | 8 | 8 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 9 wxyz | 9 | BLUETOOTH 9 | 9 | | |
| MENU | Menu | HOME MENU | Menu / Home | | |
| HELP | Help | GOTO TEXT | Text / Goto | | |
| 0 _ | 0 | HDMI - SAT 0 | 0 | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |