Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Power		Power
	Left		Left
M	Menu	HOME MENU	Menu / Home
	Right		Right
SELECT OK	OK/Select	OK	OK
	Down		Down
INFO	[i]/Info	ANGLE INFO	Info / Angle
ABC 1	1	TV 1	1
DEF 2	2	DVD 2	2
GHI 3	3	CD - STB 3	3
JKL 4	4	VIDEO 4	4
MNO 5	5	TAPE 5	5
PQR 6	6	TUNER 6	6
STU 7	7	AUX - HDD 7	7
VWX 8	8	USB 8	8

Original		Replacement	
YZ 9	9	BLUETOOTH 9	9
PP	PP	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
-/-- EXIT	-/--/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
P+	P+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
	Vol +	VOL +	Vol +
P-	P-	CH PAGE −	CH- / Page-
SWAP P<P	Swap/P<P	PC FAV MARKER	Fav / Marker / PC
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II
TV/DTV	Tv/DTV	PROGRAM TV/RADIO	TV/Radio /
SOURCE AV	AV/Source	RDS AV INPUT	AV / Input / RDS
	Red/↑	NETFLIX SEARCH	Red / Netflix / Search
	Green/↓	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	[≡]/Text	GOTO TEXT	Text / Goto

Original		Replacement		Original		Replacement
	[≡o]	TIMER SLEEP	Sleep / Timer			
	[≡+] / [+]	TITLE SOUND	Sound / Title			
	[≡x] / [■■]	SURROUND ⏏	Eject / Surround			
	[. ≡]	FORMAT PICTURE	Picture / Format			
	[≡♦] / [+] / Wide	SIZE ZOOM	Zoom / Size			
	[≡?]	EQ SUBTITLE	Subtitle / EQ			
	[≡i] / Guide	-/-- GUIDE EPG	Guide / EPG / -/--			