Original	Replacement	Original	Replacement
On / Standby	Power	Down	Down
Input Selector V	1	Right	Right
Input Selector V	2	Left	Left
Input Selector V	3	Play	Play / Slow
Input Selector Multi CH	5	Rev. Play	Pause / Step / Freeze
Input Selector	6	Stop	Stop / Hold
Input Selector	7	<<	>> / Tune+
Input Selector Tuner	8	>>	I << / Preset-
Input Selector C	9	I <<	<< / Tune-
Dimmer	0	>>I	>>I / Preset+
Sleep	Sleep / Timer	Listening Mode Stereo	Red / Netflix / Search
Guide/Top	Menu / Home	Listening Mode Surround	Green / APP / Repeat
Muting	Mute / Dimmer	Listening Mode <	Yellow / YouTube / Repeat
Return	Back / Return	Listening Mode >	Blue / Prime Video / Random
Setup	Eject / Surround	Test Tone/Audi	Audio / Lang I/II
Enter	OK	CH Sel/Subtitl	Subtitle / EQ
Up	Up	Level-/Random	TV/Radio / Program

Original		Replacement	
REPEAT LEVEL+	Level +/ Repeat	SIZE ZOOM	Zoom / Size
DISPLAY	Display	ANGLE INFO	Info / Angle
L.NIGHT DVD	L. Night	LIST SMART	Smart / List
CINE FLTR HDD	Cine FLTR	MEDIA DISPLAY	Display / Media
INPUT	Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH DISC ALBUM +	CH/ Disc/ Album	CH PAGE +	CH+ / Page+
CH DISC ALBUM -	CH/ Disc/ Album-	CH PAGE -	CH- / Page-
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
Power	Power Tv/ Standby	SHIFT +	Shift + Power
VOL +	Vol + Tv	SHIFT + VOL +	Shift + Vol +
VOL -	Vol - Tv	SHIFT + VOL -	Shift + Vol -
1	1 Tv	SHIFT + TV 1	Shift + 1
2	2 Tv	SHIFT + DVD 2	Shift + 2
3	3 Tv	SHIFT + CD-STB 3	Shift + 3
4	4 Tv	SHIFT + VIDEO 4	Shift + 4
5 MULTI CH	5 Tv	SHIFT + TAPE 5	Shift + 5

Original		Replacement	
6 DVD	6 Tv	SHIFT + TUNER 6	Shift + 6
7 TAPE	7 Tv	SHIFT + AUX-HDD 7	Shift + 7
8 TUNER	8 Tv	SHIFT + USB 8	Shift + 8
9 CD	9 Tv	SHIFT + BLUETOOTH 9	Shift + 9
0 DIMMER	0 Tv	SHIFT + HDMI-SAT 0	Shift + 0
+10	+10 Tv	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PREVIOUS MENU MUTING	Muting/ Previous Menu Tv	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
ENTER	Enter Tv	SHIFT + OK	Shift + OK
PLAYLIST/CAT+	Right Tv	SHIFT +	Shift + Right
PLAYLIST/CAT-	Left Tv	SHIFT +	Shift + Left
SETUP	Setup Tv	TOP MENU D.MENU	D. Menu / Top
	Up Tv	SHIFT +	Shift + Up
	Down Tv	SHIFT +	Shift + Down

Original	Replacement	Original	Replacement
Power	Power	Previous Menu/Muting	Mute / Dimmer
1	1	Left/Playlist/Ca	Left
2	2	Enter	OK
3	3	Right/Playlist/C	Right
4	4	Return	Back / Return
5	5	Down	Down
6	6	Setup	Setup / OPT /
7	7	Pause	Pause / Step / Freeze
8	8	Play	Play / Slow
9	9	Stop	Stop / Hold
VCR	SHIFT + VIDEO 4 Shift + 4	<<	<< / Tune-
+10/10/-/--	GUIDE EPG Guide / EPG / -/--	>>	>> / Tune+
0/11	HDMI-SAT 0	I <<	I << / Preset-
CLR	CLEAR EXIT CANCEL Exit / Cancel / Clear	>>I	>>I / Preset+
Top Menu	TOP MENU D.MENU D.Menu / Top	Stereo	Sound / Title
Up	Up	Surround	Eject / Surround
Previous Menu/Muting	HOME MENU Menu / Home	< Listening Mode	SHIFT + PRESET- Shift + I << / Preset-

Original	Replacement	Original	Replacement
Listening Mode >	SHIFT + PRESET+ Shift + >>I / Preset+		
Audio	LANG I/II AUDIO Audio / Lang I/II		
Subtitle	EQ SUBTITLE Subtitle / EQ		
Random	Prime Video RANDOM Blue / Prime Video / Random		
Repeat	APP REPEAT Green / APP / Repeat		
Display	MEDIA DISPLAY Display / Media		
Play Mode VCR	FORMAT PICTURE Picture / Format		
DVD	SHIFT + DVD 2 Shift + 2		
HDD	SHIFT + AUX-HDD 7 Shift + 7		

Original	Replacement	Original	Replacement
On / Standby	Power	Pause	Pause / Step / Freeze
1	1	Play	Play / Slow
2	2	Stop	Stop / Hold
3	3	<<	<< / Tune-
4	4	>>	>> / Tune+
5	5	I <<	I << / Preset-
6	6	>>I	>>I / Preset+
7	7	Stereo	Audio / Lang I/II
8	8	Surround	Eject / Surround
9	9	< Listening Mode	Shift + I << / Preset-
+10/10/-/--	Guide / EPG / -/--	Listening Mode >	Shift + >>I / Preset+
0/11	0	Random	Blue / Prime Video / Random
12	Fav / Marker / PC	Repeat	Green / APP / Repeat
Disc+	CH+ / Page+	Display	Display / Media
Vol +	Vol +		
Disc-	CH- / Page-		
Vol -	Vol -		

Original	Replacement	Original	Replacement
Power	Power	<<	<< / Tune-
1	1	Stereo	Audio / Lang I/II
2	2	Surround	Eject / Surround
3	3	< Listening Mode	Shift + I << / Preset-
4	4	Listening Mode >	Shift + >>I / Preset+
5	5	Play Mode	D. Menu / Top
6	6	L. Night	Sleep / Timer
7	7		
8	8		
9	9		
+10/ 10/ - / - -	Guide / EPG / - / - -		
0/ 11	0		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Pause	Pause / Step / Freeze		
Play	Play / Slow		
Stop	Stop / Hold		