Original	Replacement	Original	Replacement
Power	Power	Right	RIGHT
1	1	Left	LEFT
2	2	Enter	OK
3	3	Play/Slow	Play
4	4	Pause/Still	Pause
5	5	Stop	Stop
6	6	>>	Fast Forward
7	7	<<	Rewind
8	8	Index	INFO
9	9	Cancel	EXIT
0	0	Menu	MENU
AV	SRC	Timer Rec	WIDE
CH/TR+	CH +	Program	OPT+
CH/TR-	CH -	Call	P/C / FAV
Rec/OTR	Rec	Clock/Counter	-/-- / EPG
Up	UP	Counter Reset	MEDIA
Down	DOWN	Zero Return	BACK

Original		Replacement		Original	Replacement
SPEED SP/LP	Speed SP/ LP	V-FOR	V- FOR		
TV/VCR	Tv/ VCR	TV/R	TV/ R		
EJECT	Ej ect	VOD	VOD		