Original		Replacement	
	Power		Power
DVD	DVD	APP MEDIA	Media
iPod/USB	iPod/USB	HOME SMART	Smart
FM/EXT-IN	FM/EXT-In	TIMER AV	AV
ONE TOUCH PLAY	One touch play	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/-- ≧10	+10	-/-- GUIDE	Guide
CANCEL	Cancel	CLEAR EXIT	Exit

Original		Replacement	
VOL +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
SKIP	I<< Skip		I<<
	>>I Skip		>>I
SLOW/	<< Slow/Search		<<
SEARCH	Slow/Search >>		>>
STOP	Stop		Stop
PAUSE	Pause		Pause
PLAY	Play	PLAY MODE	Play
TOP MENU DIRECT NAVIGATOR	Top Menu/Direct Navigator	TOP MENU MENU	Menu
START	Start	FAV PRE-CH	Pre Ch
MENU PLAY LIST	Menu/Play List	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement		Original	Replacement
OK	OK	OK	Ok		
FUNCTIONS	Functions	DISC NAV LIST	List		
DD PL II	[OI O] PLI I	SOUND DUAL	Dual		
-PLAY MODE -REPEAT	Play Mode/Repeat	REPEAT TEXT	Text		
SUBWOOFER LEVEL -CH SELECT	Level/Subwoofer/ CH Select	DISPLAY INFO	Info		
-FL DISPLAY -SLEEP	FL Display-Sleep	PROG SLEEP	Sleep		
SETUP -AUTO SP	Setup/Auto SP	SETTINGS OPT	Options		
SOUND -W.S.	Sound-W.S.	AD SUBT	Subt		
MUTING	Muting	MUTE	Mute		
⏻	Power Tv	SHIFT + ⏻	Shift + Power		
TV/AV	Tv/AV Tv	SHIFT + TIMER AV	Shift + AV		
+ VOL	Vol + Tv	SHIFT + VOL −	Shift + Vol -		
VOL −	Vol - Tv	SHIFT + + VOL	Shift + Vol +		