Original		Replacement	
	Power		Power
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
SLOW/SE	<< Slow/Search	TUNE-	<< / Tune-
SEARCH	Slow/Search >>	TUNE+	>> / Tune+
SKIP	I<</Skip Down	PRESET-	I<< / Preset-
SKIP	>>I / Skip Up	PRESET+	>>I / Preset+
SUBWOOFER LEVEL	Subwoofer	TITLE SOUND	Sound / Title
FL DISPLAY	Audio Only	LANG I/II AUDIO	Audio / Lang I/II
D.RE-MASTER	Double Re-Master	EQ SUBTITLE	Subtitle / EQ
SFC	SFC	FORMAT PICTURE	Picture / Format
CENTER FOCUS	C.Focus	SIZE ZOOM	Zoom / Size
TIMER	Timer	TIMER SLEEP	Sleep / Timer
SKIP	TV	PROGRAM TV/RADIO	TV/Radio /
TOP MENU/ DIRECT NAVIGATOR	Top Menu / Direc Navigator	TOP MENU D.MENU	D.Menu / Top Menu

Original		Replacement	
MUTING	Setup	OPT-TOOLS SETUP	Setup / OPT /
SFC	Test	GOTO TEXT	Text / Goto
SEARCH	TV / AV	RDS AV INPUT	AV / Input / RDS
MENU/ PLAY LIST	Menu / Play Lis	HOME MENU	Menu / Home
	Up		Up
SUBWOOFER LEVEL	MIX 2CH	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
CANCEL	Cancel	CLEAR EXIT	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOLUME	Vol +	VOL	Vol +
FL DISPLAY	FL Display	LIST SMART	Smart / List
VOL	Vol -	VOL	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1

Menu

Original		Replacement		Original		Replacement	
2	2	DVD 2	2	GROUP	Group	SHIFT + HOME MENU	Shift + Menu /
3	3	CD - STB 3	3	PL CH SELECT	CH Select	SHIFT + OK	Shift + OK
4	4	VIDEO 4	4	P.MEMORY	Position	SHIFT + LIST SMART	Shift + Smart / List
5	5	TAPE 5	5	CENTER FOCUS FM MODE	Center Focus	SHIFT + MEDIA DISPLAY	Shift + Display / Media
6	6	TUNER 6	6	DVD/CD	DVD/CD	SHIFT + DVD 2	Shift + 2
7	7	AUX - HDD 7	7	RDS TUNER/BAND	Tuner/Band	SHIFT + TUNER 6	Shift + 6
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
≥10/-/--	-/--/>10	-/-- GUIDE EPG	Guide / EPG / -/--				
0	0	HDMI - SAT 0	0				
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat				
AV SYSTEM	Power VCR	SHIFT + ⏻	Shift + Power				
PLAY MODE	Play Mode	SHIFT + SLOW ▶	Shift + Play /				
PL CH SELECT	Dolby PL	SHIFT + TITLE SOUND	Shift + Sound / Title				
S.SRND	Super Surround	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II				
SHIFT	FM Mode	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program				
RDS TUNER/BAND	RDS	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS				