Original	Replacement	Original	Replacement
Power	Power	Prog/Check	Sleep
Drive Select	Smart	I << Skip	I <<
1	1	Skip >>I	>>I
2	2	<< Slow Search	<<
3	3	Slow Search >>	>>
4	4	Stop	Stop
5	5	Pause	Pause
6	6	Play	Play
7	7	i	Info
8	8	Exit	Exit
9	9	Direct Navigator	List
0	0	Guide	Guide
Delete	Pre Ch	Function Menu	Menu
Input Select	AV	Up	Up
CH+	Ch +	Left/<I I	Left
CH-	Ch -	OK	Ok
Showview	Format	Right/I I >	Right

Original	Replacement
Down	Down
Option	Options
Return	Back
Red	Red
Green	Green
Yellow/Create Chapter	Yellow
Blue/Manual Skip	Blue
Rec	Rec
Rec Mode	Shift + Rec
Ext Link	Media
Direct Tv Rec	TV/R
Audio	Dual
Status	3D
Display	Shift + Info
Time Slip	D. Menu
Power Tv	Shift + Power
AV Tv	Shift + AV

Original	Replacement
CH+ Tv	Shift + Ch +
CH- Tv	Shift + Ch -
Vol + Tv	Vol +
Vol - Tv	Vol -