Mandis shop

Philips RC-5721

Original	Replacement	Original	Replacement
Power	Power	OK	Ok
Open/Close	Eject	Subtitle	Subt
Home	Smart	Goto	Guide
Menu/Disc	Menu	Audio	Dual
Options	Options	[<>]	Format
Back	Back	Volume	Media
Stop	Stop	Repeat / Repeat	Text
Play	Play		
Pause	Pause		
I <	I <<		
>I	>>I		
>>	>>		
<<	<<		
Up	Up		
Down	Down		
Right	Right		
Left	Left		

https://mandis.com/en/Philips/10795-2369-replacement-remote-control-for-Philips-RC-5721-9851056836.html