Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
MENU DISPLAY	Display Menu	DISPLAY INFO	Info
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Up		Up
	Left		Left

Original		Replacement	
OK	OK	OK	Ok
	Right		Right
	Down		Down
	I <<		I <<
	I <<		<<
	>>I		>>I
	>>I		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause
DISC	DISC	B	Green
TV	TV	A	Red
TUNER	TUNER	C	Yellow
AUX/DI	AUX/DI	D	Blue
SUBTITLE	Subtitle	AD SUBT	Subt
AUDIO	Audio	SOUND DUAL	Dual
ZOOM	Zoom	ZOOM	Eject

Original		Replacement	
SETUP	Set up	TOP MENU MENU	Menu
REPEAT	Repeat	REPEAT TEXT	Text
PROG	Prog	SHIFT + PROG SLEEP	Shift + Sleep
SLEEP	Sleep	PROG SLEEP	Sleep
MUTE	Mute	MUTE	Mute
SOUND	Sound	SHIFT + SOUND DUAL	Shift + Dual
SURR	SURR	PICTURE FORMAT	Format
TV VOL +	TV Vol +	+ CH	Ch +
TV VOL −	TV Vol -	CH −	Ch -

Original	Replacement

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
MENU DISPLAY	Display Menu	DISPLAY INFO	Info
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Up		Up
	Left		Left
OK	OK	OK	Ok

Original		Replacement	
	Right		Right
	Down		Down
	I <<		I <<
	I <<		<<
	>>I		>>
	>>I		>>I
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
DISC	DISC	B	Green
TV	TV	A	Red
TUNER	TUNER	C	Yellow
AUX/DI	AUX/DI	D	Blue
SETUP	Setup	TOP MENU MENU	Menu
MUTE	Mute	MUTE	Mute
SOUND	Sound	SOUND DUAL	Dual
SURR	SURR	PICTURE FORMAT	Format
TV VOL +	TV Vol +	CH +	Ch +

Original	Replacement	Original	Replacement
TV Vol -	Ch -		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Display Menu		Info
	Vol +		Vol +
	Vol -		Vol -
	Up		Up
	Left		Left
	OK		Ok

Original		Replacement	
	Right		Right
	Down		Down
	I <<		I <<
	I <<		<<
	>>I		>>I
	>>I		>>
	Stop		Stop
	Play		Play
	DISC		Green
	TV		Red
	TUNER		Yellow
	AUX/DI		Blue
	Prog		Sleep
	Mute		Mute
	Sound		Dual
	SURR		Format
	TV Vol +		Ch +

Original	Replacement	Original	Replacement
TV VOL TV Vol -	CH Ch -		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
MENU DISPLAY	Display Menu	DISPLAY INFO	Info
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Up		Up
	Left		Left
OK	OK	OK	Ok

Original		Replacement	
	Right		Right
	Down		Down
	I <<		I <<
	I <<		<<
	>>I		>>I
	>>I		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause
DISC	DISC	B	Green
TV	TV	A	Red
TUNER	TUNER	C	Yellow
AUX/DI	AUX/DI	D	Blue
PROG	Prog	PROG SLEEP	Sleep
SETUP	Setup	TOP MENU MENU	Menu
MUTE	Mute	MUTE	Mute
SURR	SURR	PICTURE FORMAT	Format