Original	Replacement	Original	Replacement
Eject	Eject / Surround	Record/OTR	Rec / Rec Mode
Standby/On	Power	Up	Up
Menu	Menu / Home	Play	Play / Slow
Status/Exit	Exit / Cancel / Clear	>I <I/ Still	Pause / Step / Freeze
Clear	Shift + Exit / Cancel / Clear	<<	<< / Tune-
1	1	Left	Left
2	2	Right	Right
3	3	>>	>> / Tune+
4	4	P+	CH+ / Page+
5	5	Stop	Stop / Hold
6	6	Down	Down
7	7	Vol +	Vol +
8	8	P-	CH- / Page-
9	9	Mute	Mute / Dimmer
Sleep	Sleep / Timer	Vol -	Vol -
0	0	Red/SV/V+	Red / Netflix / Search
System	Smart / List	Green/Smart Picture	Green / APP / Repeat

Original	Replacement	Original	Replacement
SMART PICTURE Green/Smart	FORMAT PICTURE Picture / Format		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
INDEX Blue/Index	Prime Video RANDOM Blue / Prime Video / Random		
[=i]	ANGLE INFO Info / Angle		
TEXT Text	GOTO TEXT Text / Goto		
[=?]	TOP MENU D.MENU D.Menu / Top		
[=♦]	SIZE ZOOM Zoom / Size		
[=x]	PROGRAM TV/RADIO TV/Radio /		
[=o]	OPT-TOOLS SETUP Setup / OPT /		
[=+]	RDS AV INPUT AV / Input / RDS		