| Original | Replacement |
|---|---|
| Power Receiver | Power |
| Sleep | Sleep / Timer |
| Tv Control | Shift + Power |
| ← Input Select | CH- / Page- |
| Input Select → | CH+ / Page+ |
| Input TV | AV / Input / RDS |
| BD | 5 |
| DVD | 2 |
| CD | 3 |
| CH+ Tv | Shift + CH+ / |
| Tuner | 6 |
| iPod/USB | 8 |
| SAT/CBL | 0 |
| CH- Tv | Shift + CH- / |
| Game | 7 |
| TV | 1 |
| Signal Sel | Picture / Format |

| Original | Replacement |
|---|---|
| Vol + Tv | Shift + Vol + |
| Acous. EQ | Subtitle / EQ |
| S. Retriever | Sound / Title |
| Phase | Zoom / Size |
| Vol - Tv | Shift + Vol - |
| Auto / Direct | Red / Netflix / Search |
| Stereo | Green / APP / Repeat |
| ALC/ Standard | Yellow / YouTube / Repeat |
| Eco/ ADV Surr | Blue / Prime Video / Random |
| Audio | Audio / Lang I/II |
| Up | Up |
| Vol + | Vol + |
| Left | Left |
| Enter | OK |
| Right | Right |
| Down | Down |
| Vol - | Vol - |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Home Menu | Menu / Home | | |
| Return | Back / Return | | |
| Mute | Mute / Dimmer | | |
| I <<< / Bass- | I << / Preset- | | |
| >>I / Bass+ | >>I / Preset+ | | |
| <<< / Tre- | << / Tune- | | |
| >>> / Tre+ | >> / Tune+ | | |
| Disp | Display / Media | | |
| 4 | 4 | | |
| SB CH | Info / Angle | | |
| CH Select | SHIFT + OK — Shift + OK | | |
| Midnight | D. Menu / Top | | |
| Speakers | Setup / OPT / | | |
| Level + | SHIFT + ▲ — Shift + Up | | |
| Level - | SHIFT + ▼ — Shift + Down | | |
| Dimmer | SHIFT + DIMMER MUTE — Shift + Mute / Dimmer | | |

| Original | | Replacement | |
|---|---|---|---|
| RECEIVER | Power Receiver | | Power |
| TUNE | Tune Up | TUNE+ | >> / Tune+ |
| TOOLS MENU | Menu Tools | HOME MENU | Menu / Home |
| VOLUME + | Vol + | VOL + | Vol + |
| PRESET | Preset - | PRESET- | I << / Preset - |
| ENTER | Enter | OK | OK |
| PRESET | Preset + | PRESET+ | >>I / Preset + |
| TUNE | Tune Down | TUNE- | << / Tune- |
| − | Vol - | VOL − | Vol - |
| HOME MENU PTY iPod CTRL | PTY/iPod Control | GOTO TEXT | Text / Goto |
| BAND RETURN | Band | LIST SMART | Smart / List |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| DISP | Disp | MEDIA DISPLAY | Display / Media |
| 4 | 4 | VIDEO 4 | 4 |

| Original | | Replacement | |
|---|---|---|---|
| SB CH 5 | 5 | TAPE 5 | 5 |
| CH SELECT 6 | 6 | TUNER 6 | 6 |
| MIDNIGHT 7 | 7 | AUX - HDD 7 | 7 |
| SPEAKERS 8 | 8 | USB 8 | 8 |
| LEV + 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| DIMMER | Dimmer | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power Receiver | Power | << | << / Tune- |
| Audio | Audio / Lang I/II | >> | >> / Tune+ |
| Up | Up | Disp | Display / Media |
| Vol + | Vol + | Repeat | Green / APP / Repeat |
| Left | Left | Random | Blue / Prime Video / Random |
| Enter | OK | | |
| Right | Right | | |
| Down | Down | | |
| Vol - | Vol - | | |
| PTY/iPod Control | Text / Goto | | |
| Return | Back / Return | | |
| Pause | Pause / Step / Freeze | | |
| Stop | Stop / Hold | | |
| Play | Play / Slow | | |
| Mute | Mute / Dimmer | | |
| I << | I << / Preset- | | |
| >>I | >>I / Preset+ | | |