Mandis shop

Pioneer CU-DC014

Original	Replacement
Power	Power
Phono	Smart / List
Volume-	Vol -
Volume+	Vol +
Tuner Station-	CH- / Page-
Tuner Station+	CH+ / Page+
< Play Deck II	Shift + Left
Play > Deck II	Shift + Right
< Play Deck I	Left
Play > Deck I	Right
<< Fast Deck I	<< / Tune-
Fast >> Deck I	>> / Tune+
Stop Deck I	OK
Rec Deck II	Rec / Rec Mode
Pause Deck II	Shift + Pause / Step /
Stop Deck II	Shift + Stop /
Timer Sleep	Sleep / Timer

Original	Replacement
Stop CD	Stop / Hold
Disc	Blue / Prime Video / Random
Play CD	Play / Slow
Snooze	Display / Media
Pause CD	Pause / Step / Freeze
I<< Track Search	I<< / Preset-
Track Search >>I	>>I / Preset+

https://mandis.tv/en/Pioneer/1649582-replacement-remote-control-for-Pioneer-CU-DC014-CU-DC008.htm