| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Mute | | Mute / Dimmer |
| | Play | | Play / Slow |
| | Pause | | Pause / Step / Freeze |
| | Stop | | Stop / Hold |
| | USB Rec | | Rec / Rec Mode |
| | << | | << / Tune- |
| | >>/RDS Display | | >> / Tune+ |
| | I<<<RDS PTY | | I<< / Preset- |
| | >>I | | >>I / Preset+ |
| | Sound | | Sound / Title |
| | Speed/CD Rec | | Subtitle / EQ |
| | Sleep | | Sleep / Timer |
| | On/Off Timer | | TV/Radio / |
| | Tools | | Setup / OPT / |
| | Function | | Menu / Home |
| | Up/Tuning+ | | Up |

| Original | | Replacement | |
|---|---|---|---|
| | Info | | Info / Angle |
| | Left | | Left |
| | Enter | | OK |
| | Right | | Right |
| | Exit | | Exit / Cancel / Clear |
| | Down/Tuning- | | Down |
| | Return | | Back / Return |
| | Vol + | | Vol + |
| | DVD/Disc Skip | | Smart / List |
| | Vol - | | Vol - |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4/Disc Menu | 4 | 4 |
| 5 | 5/Title Menu | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| SYNC 8 | 8/ Sync | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| DISPLAY A | Red/ Display | NETFLIX SEARCH | Red / Netflix / Search | | |
| MO/ST TUN B | Green/ MO/ ST | APP REPEAT | Green / APP / Repeat | | |
| C | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| D | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| EQ | EQ | SHIFT + EQ SUBTITLE | Shift + Subtitle / EQ | | |
| TIMER CLOCK | Clock/ Timer | SHIFT + TIMER SLEEP | Shift + Sleep / Timer | | |
| HOME | Home | SHIFT + HOME MENU | Shift + Menu / | | |
| REPEAT | Repeat | SHIFT + APP REPEAT | Shift + Green / APP / | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |