Mandis shop

REMCON2038

Original		Replacement		Original	Replacement
ST-BY	ST-BY		Power		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
INPUT SEL	Input Sel	RDS AV INPUT	AV / Input / RDS		
MODE	Mode	FORMAT PICTURE	Picture / Format		
SURR+	Surr+	TUNE+	>> / Tune+		
CENTER+	Center+		Up		
SUB-W+	Sub-W+	CH PAGE +	CH+ / Page+		
SURR-	Surr-	TUNE-	<< / Tune-		
CENTER-	Center-		Down		
SUB-W-	Sub-W-	CH PAGE −	CH- / Page-		
VOLUME+	Volume+	VOL +	Vol+		
BALANCE R	Balance R		Right		
VOLUME-	Volume-	VOL −	Vol-		
BALANCE L	Balance L		Left		

https://mandisremotes.com/en/Silvercrest/1066564-96551-replacement-remote-control-for-Silvercrest-REMCON2038.html