Original		Replacement	
I/⏻	Power	⏻	Power
SOCIAL VIEW	Social View	APP MEDIA	Media
Input		TIMER AV	AV
DIGITAL/ ANALOG	Digital / Analog	ZOOM ⏏	Eject
EXIT	Exit	CLEAR EXIT	Exit
FOOTBALL	Football	DISC NAV LIST	List
3D	3D	ECO 3D	3D
1 ./	1	1	1
2abc	2	2	2
3def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6mno	6	6	6
7pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0 ␣	0	0	0

Original		Replacement	
RADIO TV	TV/ Radio	SEARCH TV/R	TV/ R
≡	[≡]	REPEAT TEXT	Text
Red		A	Red
Green		B	Green
Yellow		C	Yellow
Blue		D	Blue
RELATED SEARCH TrackID	X/ Related Search/ Track ID	SHIFT + SEARCH TV/R	Shift + TV/ R
SYNC MENU	Sync Menu	TOP MENU MENU	Menu
i-MANUAL ?	?/ i - Manual	E-MANUAL D.MENU	D. Menu
DISCOVER	Discover	PROG SLEEP	Sleep
[i +] / [?]		DISPLAY INFO	Info
RETURN	Return/ Back	RETURN BACK	Back
OPTIONS	Options	SETTINGS OPT	Options
HOME	Home	HOME SMART	Smart
GUIDE	Guide	- / -- GUIDE	Guide
	Up	▲	Up
	Down	▼	Down

Original		Replacement	
	Right		Right
	Left		Left
	OK	OK	Ok
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
	Recall	FAV PRE-CH	Pre Ch
PROG +	Prog+	CH +	Ch +
	Prog-	CH −	Ch -
AUDIO	Audio	SOUND DUAL	Dual
	[. . .]	AD SUBT	Subt
	[+]	PICTURE FORMAT	Format
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	I <<		I <<
	Pause		Pause

Original		Replacement	
	>>I		>>I
REC	Rec	REC MODE	Rec
	Stop		Stop
TV PAUSE	Tv Pause	SHIFT +	Shift + Pause