Original		Replacement	
I/⏻	Power	⏻	Power
⇥	Input	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
[≡] / Text		REPEAT TEXT	Text
[+]		PICTURE FORMAT	Format
🔇	Mute	MUTE	Mute
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -

Original		Replacement	
PROG +	Prog+	+ CH	Ch +
−	Prog-	CH −	Ch -
MEDIA	Media	APP MEDIA	Media
EXIT	Exit	CLEAR EXIT	Exit
RADIO TV	Tv/Radio	SEARCH TV/R	TV/R
ANALOG DIGITAL	Digital/Analog	ZOOM ⏏	Eject
✦	OK	OK	Ok
	Up	▲	Up
	Down	▼	Down
	Right	▶	Right
	Left	◀	Left
SYNC MENU	Sync Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
i-MANUAL	?/i-Manual	E-MANUAL D.MENU	D. Menu
HOME	Home	HOME SMART	Smart
OPTIONS	Options	SETTINGS OPT	Options
RETURN BACK	Return/Back	RETURN BACK	Back

Original		Replacement		Original	Replacement
	[i +]	DISPLAY INFO	Info		
SEN	SEN	FAV PRE-CH	Pre Ch		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
REC	Rec	REC MODE	Rec		
	Pause		Pause		
	Stop		Stop		
	Play	PLAY MODE	Play		
	>>		>>		
	<<		<<		
TITLE LIST	Title List	DISC NAV LIST	List		
TV PAUSE	Tv Pause	ECO 3D	3D		
	[. . .]	AD SUBT	Subt		
AUDIO	Audio	SOUND DUAL	Dual		
RELATED SEARCH	X/ Related Search	PROG SLEEP	Sleep		