| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| | Power | | Power | | 0 | | 0 |
| 5 PROG | Prog+ | CH PAGE + | CH+ / Page+ | | | | |
| | Prog- | CH PAGE − | CH- / Page- | | | | |
| 1 | 1 | TV 1 | 1 | | | | |
| 2 | 2 | DVD 2 | 2 | | | | |
| 3 | 3 | CD - STB 3 | 3 | | | | |
| TV/VTR | Tv/ VTR | PROGRAM TV/ RADIO | TV/ Radi o / | | | | |
| VOL + | Vol + | VOL + | Vol + | | | | |
| 4 | 4 | VIDEO 4 | 4 | | | | |
| 5 | 5 | TAPE 5 | 5 | | | | |
| 6 | 6 | TUNER 6 | 6 | | | | |
| DATA SCREEN | Data Screen | MEDIA DISPLAY | Di spl ay / Medi a | | | | |
| VOL - | Vol - | VOL − | Vol - | | | | |
| 7 | 7 | AUX - HDD 7 | 7 | | | | |
| 8 | 8 | USB 8 | 8 | | | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | | | |
| -/-- | -/-- | -/-- GUIDE EPG | Gui de / EPG / -/-- | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Check | Smart / List | Input Select | AV / Input / RDS |
| Clear | Exit / Cancel / Clear | Vol - | Vol - |
| On/Off Timer/Rec | Sleep / Timer | 7 | 7 |
| Power | Power | 8 | 8 |
| Prog+ | CH+ / Page+ | 9 | 9 |
| Prog- | CH- / Page- | Timer On | Green / APP / Repeat |
| Transmit | Red / Netflix / Search | Counter Reset | Yellow / YouTube / Repeat |
| 1 | 1 | Index | Info / Angle |
| 2 | 2 | -/-- | Guide / EPG / -/-- |
| 3 | 3 | 0 | 0 |
| Rec Mode | Shift + Rec / Rec Mode | Up | Up |
| Tv/VTR | TV/Radio / | PinP | Picture / Format |
| Vol + | Vol + | Shift | Text / Goto |
| 4 | 4 | Digital Off | Zoom / Size |
| 5 | 5 | Menu | Menu / Home |
| 6 | 6 | Left | Left |
| Data Screen | Display / Media | Execute | OK |

| Original | | Replacement | |
|---|---|---|---|
| | Right | | Right |
| EDIT MONITOR | Edit Monitor | EQ SUBTITLE | Subtitle / EQ |
| INDEX MARK | Index Mark | OPT-TOOLS SETUP | Setup / OPT / |
| INDEX ERASE | Index Erase | PC FAV MARKER | Fav / Marker / PC |
| | Down | | Down |
| | < Frame | SHIFT + | Shift + Left |
| FRAME | >I < Frame | SHIFT + OK | Shift + OK |
| | Frame > | SHIFT + | Shift + Right |
| PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |
| REC | Rec | REC MODE | Rec / Rec Mode |
| SLOW - | Slow- | SHIFT + CH PAGE - | Shift + CH- / |
| SLOW + | Slow+ | SHIFT + CH PAGE + | Shift + CH+ / |
| AUDIO DUB | Audio Dub | LANG I/II AUDIO | Audio / Lang I/II |
| PLAY | Play | SLOW | Play / Slow |
| HIGH SPEED REWIND | <<< High Speed Remain | RETURN BACK | Back / Return |
| SEARCH | << Search | PRESET- | I<< / Preset- |
| REW | <</ REW | TUNE- | << / Tune- |

| Original | | Replacement | |
|---|---|---|---|
| FF | >>/ FF | TUNE+ | >> / Tune+ |
| SEARCH | Search >> | PRESET+ | >>I / Preset+ |
| STOP | Stop | HOLD | Stop / Hold |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Check | Smart / List | Input Select | AV / Input / RDS |
| Clear | Exit / Cancel / Clear | Vol - | Vol - |
| On/Off Timer Rec | Sleep / Timer | 7 | 7 |
| Power | Power | 8 | 8 |
| Prog+ | CH+ / Page+ | 9 | 9 |
| Prog- | CH- / Page- | Timer On | Green / APP / Repeat |
| Transmit | Red / Netflix / Search | Counter Reset | Yellow / YouTube / Repeat |
| 1 | 1 | Index | Info / Angle |
| 2 | 2 | -/-- | Guide / EPG / -/-- |
| 3 | 3 | 0 | 0 |
| Rec Mode | Shift + Rec / Rec Mode | Up | Up |
| Tv/VTR | TV/Radio / | PinP | Picture / Format |
| Vol + | Vol + | Shift | Text / Goto |
| 4 | 4 | Digital Off | Zoom / Size |
| 5 | 5 | Menu | Menu / Home |
| 6 | 6 | Left | Left |
| Data Screen | Display / Media | Execute | OK |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Right | Right | >>/ FF | >> / Tune+ |
| Edit Monitor | Subtitle / EQ | Search >> | >>I / Preset+ |
| Index Mark | Setup / OPT / | Stop | Stop / Hold |
| Index Erase | Fav / Marker / PC | | |
| Down | Down | | |
| < Frame | Shift + Left | | |
| >I < Frame | Shift + OK | | |
| Frame > | Shift + Right | | |
| Pause | Pause / Step / Freeze | | |
| Rec | Rec / Rec Mode | | |
| Slow- | Shift + CH- / | | |
| Slow+ | Shift + CH+ / | | |
| Audio Hub | Audio / Lang I/II | | |
| Play | Play / Slow | | |
| <<< High Speed Remain | Back / Return | | |
| << search | I<< / Preset- | | |
| <</ REW | << / Tune- | | |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| CHECK | Check | SMART | Smart / List | INPUT SELECT | Input Select | RDS AV INPUT | AV / Input / RDS |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear | VOL - | Vol - | VOL - | Vol - |
| (ON/OFF) | On/Off Timer Rec | TIMER SLEEP | Sleep / Timer | 7 | 7 | AUX - HDD 7 | 7 |
| | Power | | Power | 8 | 8 | USB 8 | 8 |
| 5 PROG | Prog+ | CH PAGE + | CH+ / Page+ | 9 | 9 | BLUETOOTH 9 | 9 |
| | Prog- | CH PAGE - | CH- / Page- | TIMER ON SCREEN | Timer On | APP REPEAT | Green / APP / Repeat |
| 6 TRANSMIT | Transmit | NETFLIX SEARCH | Red / Netflix / Search | COUNTER RESET | Counter Reset | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 1 | 1 | TV 1 | 1 | INDEX | Index | ANGLE INFO | Info / Angle |
| 2 | 2 | DVD 2 | 2 | -/-- | -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 3 | 3 | CD - STB 3 | 3 | 0 | 0 | HDMI - SAT 0 | 0 |
| REC MODE | Rec Mode | SHIFT + REC MODE | Shift + Rec / Rec Mode | | Up | | Up |
| TV/VTR | Tv/VTR | PROGRAM TV/RADIO | TV/Radio / | PinP | PinP | FORMAT PICTURE | Picture / Format |
| VOL + | Vol + | VOL + | Vol + | SHIFT | Shift | GOTO TEXT | Text / Goto |
| 4 | 4 | VIDEO 4 | 4 | DIGITAL OFF | Digital Off | SIZE ZOOM | Zoom / Size |
| 5 | 5 | TAPE 5 | 5 | MENU | Menu | HOME MENU | Menu / Home |
| 6 | 6 | TUNER 6 | 6 | | Left | | Left |
| DATA SCREEN | Data Screen | MEDIA DISPLAY | Display / Media | EXECUTE | Execute | OK | OK |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| | Right | | Right | FF | >>/ FF | TUNE+ | >> / Tune+ |
| EDIT MONITOR | Edit Monitor | EQ SUBTITLE | Subtitle / EQ | SEARCH | Search >> | PRESET+ | >>I / Preset+ |
| INDEX MARK | Index Mark | OPT-TOOLS SETUP | Setup / OPT / | STOP | Stop | HOLD | Stop / Hold |
| INDEX ERASE | Index Erase | PC FAV MARKER | Fav / Marker / PC | | | | |
| | Down | | Down | | | | |
| | < Frame | SHIFT | + Shift + Left | | | | |
| FRAME | >I < Frame | SHIFT | + OK Shift + OK | | | | |
| | Frame > | SHIFT | + Shift + Right | | | | |
| PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze | | | | |
| REC | Rec | REC MODE | Rec / Rec Mode | | | | |
| SLOW- | Slow- | SHIFT | + CH PAGE Shift + CH- / | | | | |
| SLOW+ | Slow+ | SHIFT | + CH PAGE Shift + CH+ / | | | | |
| AUDIO DUB | Audio Dub | LANG I/II AUDIO | Audio / Lang I/II | | | | |
| PLAY | Play | SLOW | Play / Slow | | | | |
| HIGH SPEED REWIND | <<</ High Speed Rewind | RETURN BACK | Back / Return | | | | |
| SEARCH | << Search | PRESET- | I<< / Preset- | | | | |
| REW | <</ REW | TUNE- | << / Tune- | | | | |