Original	Replacement	Original	Replacement
Standby	Power	Down	Down
Mute	Mute	Right	Right
P/N	Smart	Left	Left
Open/Close	Eject	OK	Ok
<<	<<	Vol +	Vol +
>>	>>	Vol -	Vol -
Play/Pause	Play	1	1
Stop	Stop	2	2
I <<	I <<	3	3
>>I	>>I	4	4
Setup	Options	5	5
Source	AV	6	6
Info	Info	7	7
Return/Exit	Exit	8	8
CH+	Ch +	9	9
CH-	Ch -	0	0
Up	Up	Slow	Back

Original	Replacement	Original	Replacement
GOTO Goto	APP MEDIA Media		
PROGRAM Program	PROG SLEEP Sleep		
TITLE/TTX Title/TTX	REPEAT TEXT Text		
AUDIO Audio	SOUND DUAL Dual		
SUBTITLE Subtitle	AD SUBT Subt		
REPEAT Red/Repeat	A Red		
A-B Green/A-B	B Green		
MENU Yellow/Menu	C Yellow		
ANGLE Blue/Angle	D Blue		
EPG EPG	-/-- GUIDE Guide		
FAVORITE Favorite	FAV PRE-CH Pre Ch		
TV/RADIO Tv/Radio	SEARCH TV/R TV/R		
ZOOM Zoom	SHIFT + ZOOM Shift + Eject		