Mandis shop

TP114

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Mute | MUTE | Mute |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| | Tv/Radio | SEARCH TV/R | TV/R |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |

| Original | | Replacement | |
|---|---|---|---|
| OK LIST | OK/List | OK | Ok |
| MENU | Menu | TOP MENU MENU | Menu |
| EXIT | Exit | CLEAR EXIT | Exit |
| GUIDE | Guide | -/-- GUIDE | Guide |
| | Recall | RETURN BACK | Back |
| FAV | Green/FAV | B | Green |
| | Red/Audio/Subtitl | A | Red |
| UHF | Yellow/UHF | C | Yellow |
| i | Blue/i | D | Blue |

https://mandisremotes.com/en/Topfield/1061981-66153-replacement-remote-control-for-Topfield-TP114.html