Mandis shop

bomaker Tapio I

Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
BT	BT	BLUETOOTH 9	9
BT	BT	NETFLIX SEARCH	Red / Netflix / Search
OPITICAL	Optical	APP REPEAT	Green / APP / Repeat
USB	USB	USB 8	8
USB	USB	YouTube REPEAT A-B	Yellow / YouTube / Repeat
LINE IN	Line In	Prime Video RANDOM	Blue / Prime Video / Random
+	+		Up
+	+	+ VOL	Vol +
	I <<	PRESET-	I << / Preset-
	I <<		Left
	Play/Pause	SLOW	Play / Slow
	Play/Pause	OK	OK
	>>I	PRESET+	>>I / Preset+
	>>I		Right
-	-	VOL -	Vol -

Original		Replacement	
-	-		Down
3D	3D	CD - STB 3	3
BT EX.	BT Ex	RDS AV INPUT	AV / Input / RDS
	General	LIST SMART	Smart / List
	Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Treble	OPT-TOOLS SETUP	Setup / OPT /
	Voice	LANG I/II AUDIO	Audio / Lang I/II
	Treble+	+ CH PAGE	CH+ / Page+
	Treble-	CH PAGE -	CH- / Page-

https://mandis.es/es/bomaker/1035-987-replacement-remote-control-for-bomaker-tapio-i.html