Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
VOL+	Vol +	+ VOL	Vol +
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
NICAM	Nicam	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement	
CH+	CH +	+ CH PAGE	CH+ / Page+
VOL-	Vol -	VOL -	Vol -
INPUT	Input	RDS AV INPUT	AV / Input / RDS
CH-	CH -	CH PAGE -	CH- / Page-
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DISPLAY	Display	MEDIA DISPLAY	Display / Media
PMODE	PMode	FORMAT PICTURE	Picture / Format
SMODE	S. Mode	TITLE SOUND	Sound / Title
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
FAV-	FAV -	SHIFT +	Shift + Down

Original	Replacement	Original	Replacement
FAV +	SHIFT + ▲ Shift + Up	MEDIA Media	SHIFT + MEDIA DISPLAY Shift + Display / Media
EPG	-/-- GUIDE EPG Guide / EPG / -/--	TV/RADIO Red / TV/Radio	PROGRAM TV/RADIO TV/Radio /
TEXT	GOTO TEXT Text / Goto	TV/RADIO Red / TV/Radio	NETFLIX SEARCH Red / Netflix / Search
HOLD	SHIFT + HOLD ■ Shift + Stop /	Green	APP REPEAT Green / APP / Repeat
LANG	SHIFT + LANG I/II AUDIO Shift + Audio / Lang I/II	Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat
SUBTITLE	EQ SUBTITLE Subtitle / EQ	Blue	Prime Video RANDOM Blue / Prime Video / Random
INDEX/◀◀ Index / <<	TUNE- ◀◀ << / Tune-		
INDEX/◀◀ Index / <<	ANGLE INFO Info / Angle		
SIZE/▶▶ Size / >>	TUNE+ ▶▶ >> / Tune+		
SIZE/▶▶ Size / >>	SIZE ZOOM Zoom / Size		
REVEAL/⏮ Reveal / I<<	PRESET- ⏮ I<< / Preset-		
SUBPAGE/⏭ Subpage / >>I	PRESET+ ⏭ >>I / Preset+		
SUBPAGE/⏭ Subpage / >>I	SURROUND ⏏ Eject / Surround		
REC Rec	REC MODE ● Rec / Rec Mode		
▶II Play / Pause	SLOW ▶ Play / Slow		
▶II Play / Pause	STEP-FREEZE II Pause / Step / Freeze		
■ Stop	HOLD ■ Stop / Hold		