Original		Sustituto	
	Power Tuner		Power
	Mute		MUTE
	1 Tuner		1
	2 Tuner		2
	3 Tuner		3
	4 Tuner		4
	5 Tuner		5
	6 Tuner		6
	7 Tuner		7
	8 Tuner		8
	9 Tuner		9
	0 Tuner		0
	Cinema Go		-/-- / EPG
	Vol +		VOL +
	Vol -		VOL -
	Play Tuner/Phono/Cable Box		Play
	Stop Tuner/Phono/Cable Box		Stop

Original		Sustituto	
	Loudness		Subt.
	Subw. On/Off		VOD
	Mode/Virtual		OPT+
	Night		WIDE
	Surround On/Off		MEDIA
	Channel/Rear +		CH +
	Channel/Rear -		CH -
	Surround Mode		TV/R
	Test Tone		EXIT
	Sub woofer +		Green (B)
	Sub Woofer -		Red (A)
	Right Tuner		RIGHT
	Up Tuner		UP
	Down Tuner		DOWN
	Left Tuner		LEFT
	OK Tuner		OK
	Menu / Guide		MENU

Tuner

Original		Sustituto	
NEWS/TA	i / News/ TA	INFO	I NFO
CHANNE	I < Channel / Track		First
L/TRACK	Channel / Track >I Tuner		Last
FR.D.	Pause/ FR. D.		Pause
TUNER	Tuner	SHIFT + VOD	Shift + VOD
PHONO	Phono	SHIFT + MEDIA	Shift + MEDI A
	Power Phono	SHIFT +	Shift + Power

Original	Sustituto

Original		Sustituto	
	Power Tv		Power
TV	TV	D	Blue (D)
MUTE	Mute Tv		MUTE
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7
8	8 Tv	8	8
9	9 Tv	9	9
0	0 Tv	0	0
GUIDE MENU	Menu/Guide Tv	MENU	MENU
OK	OK Tv	OK	OK
	Up Tv	▲	UP
	Down Tv	▼	DOWN

Original		Sustituto	
	Right Tv	▶	RIGHT
	Left Tv	◀	LEFT
+	Vol + Tv/CD	+ VOL	VOL +
−	Vol - Tv/CD	VOL −	VOL -
▶	Play Tv	▶	Play
■	Stop Tv	■	Stop
i NEWS/TA	i/News/TA Tv	INFO	INFO
CHANNE	I< Channel/Track	⏮	First
L/TRACK	Channel/Track >I	⏭	Last
	Power CD	SHIFT +	Shift + Power
CD	CD	C	Yellow (C)
MUTE	Mute CD	SHIFT +	Shift + MUTE
1	1 CD	SHIFT + 1	Shift + 1
2	2 CD	SHIFT + 2	Shift + 2
3	3 CD	SHIFT + 3	Shift + 3
4	4 CD	SHIFT + 4	Shift + 4
5	5 CD	SHIFT + 5	Shift + 5

Original		Sustituto		Original		Sustituto	
6	6 CD	SHIFT + 6	Shift + 6				
7	7 CD	SHIFT + 7	Shift + 7				
8	8 CD	SHIFT + 8	Shift + 8				
9	9 CD	SHIFT + 9	Shift + 9				
0	0 CD	SHIFT + 0	Shift + 0				
	Up CD	SHIFT + ▲	Shift + UP				
	Down CD	SHIFT + ▼	Shift + DOWN				
	Right CD	SHIFT + ▶	Shift + RIGHT				
	Left CD	SHIFT + ◀	Shift + LEFT				
i NEWS/TA	i / News/TA CD	SHIFT + INFO	Shift + INFO				
■	Stop CD	SHIFT + ■	Shift + Stop				
▶	Play CD	❚❚	Pause				
CHANNE	I < CD	◀◀	Rewind				
L/TRACK	>I CD	▶▶	Fast Forward				
FR.D.	Pause/FR.D. CD	SHIFT + ❚❚	Shift + Pause				
CANCEL	: >/Cancel CD	EXIT	EXIT				
DVD DISC	Disc/DVD CD	VOD	VOD				

Original		Sustituto	
	Power SAT		Power
SAT	SAT	C	Yellow (C)
1	1 SAT	1	1
2	2 SAT	2	2
3	3 SAT	3	3
4	4 SAT	4	4
5	5 SAT	5	5
6	6 SAT	6	6
7	7 SAT	7	7
8	8 SAT	8	8
9	9 SAT	9	9
0	0 SAT	0	0
MUTE	Mute SAT		MUTE
+	Vol + SAT/DVD	+ VOL	VOL +
–	Vol - SAT/DVD	VOL –	VOL -
	Play SAT		Play
	Stop SAT		Stop

Original		Sustituto	
NEWS/TA	i/News/TA SAT	INFO	INFO
GUIDE MENU	Menu/Guide	MENU	MENU
OK	OK SAT	OK	OK
	Up SAT	▲	UP
	Down SAT	▼	DOWN
	Right SAT	▶	RIGHT
	Left SAT	◀	LEFT
CHANNE	I< Channel/Track SAT		First
L/TRACK	Channel/Track >I SAT		Last
CANCEL	:>/Cancel SAT	EXIT	EXIT
INDEX T·C	T·C/Index SAT	BACK	BACK
	Power DVD	SHIFT +	Shift + Power
DVD	DVD	D	Blue (D)
1	1 DVD	SHIFT + 1	Shift + 1
2	2 DVD	SHIFT + 2	Shift + 2
3	3 DVD	SHIFT + 3	Shift + 3
4	4 DVD	SHIFT + 4	Shift + 4

Original		Sustituto		Original		Sustituto	
5	5 DVD	SHIFT + 5	Shift + 5	DVD DISC	Disc DVD	VOD	VOD
6	6 DVD	SHIFT + 6	Shift + 6	REC AUDIO	Audio DVD		Audio
7	7 DVD	SHIFT + 7	Shift + 7	CANCEL	:>/ Cancel DVD	SHIFT + EXIT	Shift + EXIT
8	8 DVD	SHIFT + 8	Shift + 8	FR.D.	Pause/ FR. D.	SHIFT + II	Shift + Pause
9	9 DVD	SHIFT + 9	Shift + 9	INDEX T-C	T· C/ Index DVD	SHIFT + BACK	Shift + BACK
0	0 DVD	SHIFT + 0	Shift + 0				
GUIDE MENU	Menu/ Guide	SHIFT + MENU	Shift + MENU				
OK	OK DVD	SHIFT + OK	Shift + OK				
	Up DVD	SHIFT + ▲	Shift + UP				
	Down DVD	SHIFT + ▼	Shift + DOWN				
	Right DVD	SHIFT + ▶	Shift + RIGHT				
	Left DVD	SHIFT + ◀	Shift + LEFT				
▶	Play DVD	II	Pause				
■	Stop DVD	SHIFT + ■	Shift + Stop				
i NEWS/TA	i / News/ TA DVD	SHIFT + INFO	Shift + INFO				
CHANNE	I< Channel / Track DVD	◀◀	Rewind				
L/TRACK	Channel / Track >I DVD	▶▶	Fast Forward				

Original		Sustituto	
	Power VCR		Power
VCR	VCR	C	Yellow (C)
MUTE	Mute VCR		MUTE
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
GUIDE MENU	Menu/Guide	MENU	MENU
	Up VCR		UP
OK	OK VCR	OK	OK
	Down VCR		DOWN

Original		Sustituto	
	Right VCR		RIGHT
	Left VCR		LEFT
	Vol + VCR	+ VOL	VOL +
	Vol - VCR	VOL −	VOL -
	Play VCR		Play
	Stop VCR		Stop
CHANNE	I< Channel/Track VCR		First
L/TRACK	Channel/Track >I VCR		Last
REC AUDIO	Rec VCR		Rec
CANCEL	:>/Cancel VCR	EXIT	EXIT
FR.D.	Pause/FR.D VCR		Pause
INDEX T·C	T·C/Index VCR	BACK	BACK
	Power	SHIFT +	Shift + Power
CDR/TAPE	CDR/Tape	D	Blue (D)
1	1 CDR/Tape	SHIFT + 1	Shift + 1
2	2 CDR/Tape	SHIFT + 2	Shift + 2
3	3 CDR/Tape	SHIFT + 3	Shift + 3

Original	Sustituto	Original	Sustituto
4 CDR/Tape	SHIFT + 4 Shift + 4	DVD DISC Disc CDR/Tape	VOD VOD
5 CDR/Tape	SHIFT + 5 Shift + 5		
6 CDR/Tape	SHIFT + 6 Shift + 6		
7 CDR/Tape	SHIFT + 7 Shift + 7		
8 CDR/Tape	SHIFT + 8 Shift + 8		
9 CDR/Tape	SHIFT + 9 Shift + 9		
0 CDR/Tape	SHIFT + 0 Shift + 0		
Up CDR/Tape	SHIFT + ▲ Shift + UP		
Down CDR/Tape	SHIFT + ▼ Shift + DOWN		
Right CDR/Tape	SHIFT + ▶ Shift + RIGHT		
Left CDR/Tape	SHIFT + ◀ Shift + LEFT		
i / News/TA	INFO INFO		
I< Channel / Track CDR/Tape	Rewind		
Channel / Track >I CDR/Tape	Fast Forward		
Rec CDR/Tape	WIDE WIDE		
:>/ Cancel	SHIFT + EXIT Shift + EXIT		
Pause/FR.D. CDR/Tape	SHIFT + ❚❚ Shift + Pause		