Original		Sustituto		Original		Sustituto	
STANDBY	Standby		Power	VOL+	Vol +	VOL	Vol +
REC	Rec PVR	REC MODE	Rec / Rec Mode	VOL+	Right		Right
LIST	PVR List	LIST SMART	Smart / List	FAVOURITE	Favourite	PC FAV MARKER	Fav / Marker / PC
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	CH-	CH-	CH PAGE	CH- / Page-
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--	CH-	Down		Down
INFO	Info	ANGLE INFO	Info / Angle	TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
TTX	TTX	GOTO TEXT	Text / Goto	1	1	TV 1	1
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II	2	2	DVD 2	2
DTV/VCR	DTV/VCR	RDS AV INPUT	AV / Input / RDS	3	3	CD-STB 3	3
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ	RECALL	Recall	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home	4	4	VIDEO 4	4
CH+	Up		Up	5	5	TAPE 5	5
CH+	CH+	CH PAGE	CH+ / Page+	6	6	TUNER 6	6
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear	GOTO	Goto	SHIFT + GOTO TEXT	Shift + Text /
VOL-	Left		Left	7	7	AUX-HDD 7	7
VOL-	Vol -	VOL	Vol -	8	8	USB 8	8
OK	OK	OK	OK	9	9	BLUETOOTH 9	9

Original		Sustituto	
0	0	0	0
REV	<<	TUNE-	<< / Tune-
FWD	>>	TUNE+	>> / Tune+
PREV	I<<	PRESET-	I<< / Preset-
NEXT	>>I	PRESET+	>>I / Preset+
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original	Sustituto