Original		Sustituto	
ON/ STAND-BY	On/ Standby		Power
+	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
7	7	7	7
6	6	6	6
8	8	8	8
9	9	9	9
0	0	0	0
+10	+10	-/-- GUIDE	Guide
C D	CD	A	Red
TUNER (BAND)	Tuner (Band)	B	Green
TAPE (1 ⇔ 2)	Tape (1-2)	C	Yellow

Original		Sustituto	
GAME / VIDEO	Game/ Video	D	Blue
MEMORY	Memory	REC MODE	Rec
	Play CD	PLAY MODE	Play
	Stop CD		Stop
	Pause CD		Pause
RANDOM	Random CD	APP MEDIA	Media
CLEAR/ DIMMER	Clear/ Dimmer	CLEAR EXIT	Exit
	Play Tape	HOME SMART	Smart
	Stop Tape	SHIFT +	Shift + Stop
	Rec/ Pause Tape	SHIFT +	Shift + Pause
CURSOR	Up		Up
CURSOR	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
DISPLAY	Display	DISPLAY INFO	Info
NAVIGATION	Navigator	TOP MENU MENU	Menu

Original		Sustituto		Original	Sustituto
CHARACTER	Character	RETURN BACK	Back		
CLOCK / TIMER	Clock/Timer	TIMER AV	AV		
SET ▲ ▶▶ ▶▶I	>>I / >>/ Up	+ CH	Ch +		
▼ PR ◀◀ I◀◀	I <</ <</ Down	CH −	Ch -		
EQUALIZER MODE	Equalizer Mode	SOUND DUAL	Dual		
X-BASS (SURROUND)	X-Bass/Surroun	AD SUBT	Subt		
DISC SELECT 1	Select Drive 1	SHIFT + 1	Shift + 1		
2	Select Drive 2	SHIFT + 2	Shift + 2		
3	Select Drive 3	SHIFT + 3	Shift + 3		
4	Select Drive 4	SHIFT + 4	Shift + 4		
5	Select Drive 5	SHIFT + 5	Shift + 5		