Mandis shop

Philips 996580005709

Original		Sustituto	
	Power		Power
AUDIO IN	Audio In	1	1
AUX	AUX	2	2
OPTICAL	Optical	3	3
HDMI IN	HDMI In	4	4
	Bluetooth	5	5
HDMI ARC	HDMI ARC	6	6
	I<	K<	I<<
	Play	PLAY MODE	Play
	Pause	II	Pause
	>I	>>	>>I
BASS +	Bass+		Up
BASS −	Bass-		Down
TREBLE +	Treble+	CH +	Ch +
TREBLE −	Treble-	CH −	Ch -
+	Vol +	VOL +	Vol +
−	Vol -	VOL −	Vol -

Original		Sustituto	
	Mute	MUTE	Mute
SOUND	Sound	SOUND DUAL	Dual
AUDIO SYNC +	Audio Sync+		Right
AUDIO SYNC −	Audio Sync -		Left
DELAY	Delay Settings	DISPLAY INFO	Info
VOL	Vol Settings	TOP MENU MENU	Menu
NIGHT	Night	RETURN BACK	Back
DIM EXIT SETTINGS	DIM/Exit Setting	CLEAR EXIT	Exit

https://mandis.es/es/Philips/1669-609-mando-sustituto-para-Philips-996580005709.htm