Original		Sustituto	
DVD	Power		Power
DRIVE SELECT	Drive Select	HOME SMART	Smart
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DELETE *	Delete	-/-- GUIDE	Guide
INPUT SELECT	Input Select	TIMER AV	AV
CH+	CH+	+ CH	Ch +
CH-	CH-	CH −	Ch -
ShowView	Showview	PICTURE FORMAT	Format

Original		Sustituto	
STATUS	Status	ECO 3D	3D
SKIP	I<< Skip		I<<
SKIP	Skip >>I		>>I
SLOW/SEARCH	<< Slow Search		<<
SLOW/SEARCH	Slow Search >>		>>
STOP	Stop		Stop
PAUSE	Pause		Pause
PLAY/x1.3	Play	PLAY MODE	Play
TIME SLIP	Time Slip	DISPLAY INFO	Info
EXIT	Exit	CLEAR EXIT	Exit
DIRECT NAVIGATOR	Direct Navigator	DISC NAV LIST	List
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep
FUNCTION MENU	Function Menu	TOP MENU MENU	Menu
OPTION	Option	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	Up		Up
	Down		Down

Original	Sustituto	Original	Sustituto
Right / II >	Right		
Left / <II	Left		
OK	Ok		
Red/ Audio	Red		
Green/ Display	Green		
Yellow/ Create Chapter	Yellow		
Blue/ Manual Skip	Blue		
Rec	Rec		
Rec Mode	SHIFT + REC MODE Shift + Rec		
Ext Link	APP MEDIA Media		
Dirtect Tv Rec	SEARCH TV/R TV/R		
Power Tv	SHIFT + Power Shift + Power		
AV Tv	SHIFT + TIMER AV Shift + AV		
CH+ Tv	SHIFT + CH + Shift + Ch +		
CH- Tv	SHIFT + CH − Shift + Ch -		
Vol + Tv	VOL + Vol +		
Vol - Tv	VOL − Vol -		