Mandis shop

LG COV33552407

Original	Sustituto
Power	Power
Sleep	SHIFT + Power (Shift + Power)
Vol +	V+
Vol -	V-
Mute	Mute
F	1 / Setup
Preset / Folder Up	+
Preset / Folder	-
Program /	2 / Menu
Dimmer	9 / Disp
Delete	3 / Exit
Sound Effect	5 / Audio
Repeat	7 / Rep
Info	4 / Mode
I<< / Tuning -	I<
Play	Play / Band
Pause	II Ang

Original	Sustituto
>>I / Tuning +	>I
Stop	Stop / Random
RDS	-- / Sear
PTY	0 / Zoom

https://mandisremotes.com/LG-COV33552407.htm