Original	Sustituto	Original	Sustituto
Power	Power	Up	Up
Open/ Close	Eject	Down	Down
DVD	Red	Right	Right
Tuner	Green	Left	Left
Video	Yellow	Enter	Ok
TV/ AUX	Blue	Vol +	Vol +
Sleep	Sleep	Vol -	Vol -
I <<	I <<	Mute	Mute
<<	<<	Set up	Options
>>	>>	Pause/ Step	Pause
>>I	>>I	Menu/ Return	Menu
Play	Play	Goto Auto	Back
Stop	Stop	1	1
SP. Set up	Media	2	2
CH- Level	Guide	3	3
SR. Mode	List	4	4
Title	Info	5	5

Original		Sustituto	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DISP/FM MODE	DISP/FM mode	SEARCH TV/R	TV/R
DELAY TIME	Delay Time	CLEAR EXIT	Exit
TEST TONE	Test Tone	PICTURE FORMAT	Format
SUBTITLE	Subtitle	AD SUBT	Subt
SLOW	Slow	TIMER AV	AV
AUDIO	Audio	SOUND DUAL	Dual
A-B	A-B	HOME SMART	Smart
ZOOM	Zoom	SHIFT + ZOOM ⏏	Shift + Eject
ANGLE	Angle	ECO 3D	3D
RANDOM	Random	E-MANUAL D.MENU	D. Menu
REPEAT	Repeat	REPEAT TEXT	Text
DIGEST RDS MODE	Digest RDS Mode	SHIFT + AD SUBT	Shift + Subt

Original		Sustituto	
MPX PTY SEARCH	MPX PTY Search	SHIFT + TIMER AV	Shift + AV
PBC	PBC	SHIFT + SEARCH TV/R	Shift + TV/R