Original	Sustituto
Source	AV / Input / RDS
Power	Power
TV	Smart / List
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Text	Text / Goto
0	0
Info	Info / Angle
Picture	Picture / Format
Menu	Menu / Home

Original	Sustituto
PRG +	CH+ / Page+
Up	Up
Sound	Sound / Title
Left	Left
Vol -	Vol -
Right	Right
Vol +	Vol +
CTRL	Display / Media
PRG -	CH- / Page-
Down	Down
Mute	Mute / Dimmer
Exit	Exit / Cancel / Clear
Size / Audio	Shift + Zoom /
Size / Audio	Audio / Lang I/II
Still / Subt	Pause / Step / Freeze
Still / Subt	Subtitle / EQ
PIP / REP	Shift + Green / APP / Repeat

Original	Sustituto
Focus / A-B	SHIFT + YouTube / REPEAT A-B (Shift + Yellow / YouTube /)
Normal / Titl	SHIFT + TITLE / SOUND (Shift + Sound / Title)
CVBS1 / Back	SHIFT + TV 1 (Shift + 1)
CVBS1 / Back	RETURN / BACK (Back / Return)
CVBS2 / OK	SHIFT + DVD 2 (Shift + 2)
CVBS2 / OK	OK (OK)
CVBS3 / Zoom	SHIFT + CD-STB 3 (Shift + 3)
CVBS3 / Zoom	SIZE / ZOOM (Zoom / Size)
Y Pb Pr / Rotat	SHIFT + VIDEO 4 (Shift + 4)
YC1 / Left	SHIFT + TAPE 5 (Shift + 5)
YC1 / Left	SHIFT + ◀ (Shift + Left)
YC2 / Right	SHIFT + TUNER 6 (Shift + 6)
YC2 / Right	SHIFT + ▶ (Shift + Right)
PC / Up	PC / FAV MARKER (Fav / Marker / PC)
PC / Up	SHIFT + ▲ (Shift + Up)
DVI / HDMI / Dow	SHIFT + HDMI-SAT 0 (Shift + 0)
DVI / HDMI / Dow	SHIFT + ▼ (Shift + Down)

Original	Sustituto
[≡?] / MTS	TOP MENU / D.MENU (D. Menu / Top)
[≡] / Sleep	TIMER / SLEEP (Sleep / Timer)
[≡i] / Time	OPT-TOOLS / SETUP (Setup / OPT /)
[≡] / PREPG	PROGRAM / TV/RADIO (TV/Radio /)
Red / Delete	NETFLIX / SEARCH (Red / Netflix / Search)
Green / Skip	APP / REPEAT (Green / APP / Repeat)
Yellow / Inser	YouTube / REPEAT A-B (Yellow / YouTube / Repeat)
Blue / Replace	Prime Video / RANDOM (Blue / Prime Video / Random)