Original		Sustituto	
VCR/DVD	Power		Power
ShowView	ShowView	LIST SMART	Smart / List
REC CHECK	Rec Check	SHIFT +	REC MODE Shift + Rec / Rec Mode
EXT LINK	Ext Link	GOTO TEXT	Text / Goto
REC	Rec	REC MODE	Rec / Rec Mode
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
TRACKING/V-LOCK CH	Tracking/V-Lock+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	Tracking/V-Lock-	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol +	+ VOL	Vol +

Original		Sustituto	
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
−	Vol -	VOL −	Vol -
INDEX/	I<< Index	PRESET-	I<< / Preset-
EX/SKIP	Index >>I	PRESET+	>>I / Preset+
SLOW/SE	<<	TUNE-	<< / Tune-
/SEARCH	>>	TUNE+	>> / Tune+
■	Stop	HOLD ■	Stop / Hold
II/I▶	Pause/Step	STEP-FREEZE II	Pause / Step / Freeze
▶	Play	SLOW ▶	Play / Slow
PROG PLAY	Prog Play	TOP MENU D.MENU	D.Menu / Top
▲	Up	▲	Up
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right

Original		Sustituto		Original		Sustituto	
DISPLAY	Display	MEDIA DISPLAY	Display / Media				
▼	Down	▼	Down				
EXIT RETURN	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
PROG/CHECK	Prog/Check	PROGRAM TV/RADIO	TV/Radio /				
TIMER	Timer	TIMER SLEEP	Sleep / Timer				
VCR/DVD OUTP	Output	EQ SUBTITLE	Subtitle / EQ				
AV LINK/SUBTITLE	AV Link	SURROUND ⏏	Eject / Surround				
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II				
MUSIC w/PICTURE	Music w/Pictur	OPT-TOOLS SETUP	Setup / OPT /				
OFF TIMER TV ASPECT	Tv Aspect/Off	FORMAT PICTURE	Picture / Format				
CANCEL/RESET A	A/Cancel Reset	NETFLIX SEARCH	Red / Netflix / Search				
I-TIMER B CINEMA	B/I-Timer	APP REPEAT	Green / APP / Repeat				
SP/LP/EP C GROUP	C/SP/LP/EP	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
VPS/PDC D SETUP	D/VPS/PDC	Prime Video RANDOM	Blue / Prime Video / Random				

Original		Sustituto	
VCR/DVD	Power		Power
REC CHECK	Rec Check	SHIFT + REC MODE	Shift + Rec / Rec Mode
EXT LINK	Ext Link	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
TRACKING/V-LOCK CH	Tracking/V-Lock/	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	Tracking/V-Lock/	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol +	+ VOL	Vol +
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0

Original		Sustituto	
-/--	>10	GUIDE EPG	Guide / EPG / -/--
−	Vol -	VOL −	Vol -
INDEX/	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
SLOW/SEARCH	<< Slow/Search	TUNE-	<< / Tune-
SEARCH	Slow/Search >>	TUNE+	>> / Tune+
■	Stop	HOLD ■	Stop / Hold
II/I▶	Pause/Step	STEP-FREEZE II	Pause / Step / Freeze
▶	Play	SLOW ▶	Play / Slow
PROG PLAY	Top Menu/Direct Navigator	TOP MENU D.MENU	D.Menu / Top
▲	Up	▲	Up
MENU PLAY LIST	Play List	LIST SMART	Smart / List
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
DISPLAY	Display	MEDIA DISPLAY	Display / Media
▼	Down	▼	Down

Original	Sustituto	Original	Sustituto
EXIT / RETURN — Return	RETURN / BACK — Back / Return		
TIMER — Timer	TIMER / SLEEP — Sleep / Timer		
QUICK REPLAY — Quick Replay	HOME / MENU — Menu / Home		
VCR/DVD / OUTP — Output	SURROUND — Eject / Surround		
AV LINK/SUBTITLE — Subtitle	EQ / SUBTITLE — Subtitle / EQ		
AUDIO — Audio	LANG I/II / AUDIO — Audio / Lang I/II		
ANGLE/PAGE — Angle/Page	ANGLE / INFO — Info / Angle		
MUSIC w/PICTURE — Music w/Pictur	FORMAT / PICTURE — Picture / Format		
OFF TIMER / TV ASPECT — Play Mode	TITLE / SOUND — Sound / Title		
ZOOM — Zoom	SIZE / ZOOM — Zoom / Size		
REPEAT — Repeat	SHIFT + APP / REPEAT — Shift + Green / APP /		
POSITION MEMORY — Position	PC / FAV MARKER — Fav / Marker / PC		
CANCEL/RESET / A — A/Cancel Reset	NETFLIX / SEARCH — Red / Netflix / Search		
I-TIMER / B / CINEMA — B/Cinema	APP / REPEAT — Green / APP / Repeat		
SP/LP/EP / C / GROUP — C/Group	YouTube / REPEAT A-B — Yellow / YouTube / Repeat		
VPS/PDC / D / SETUP — D/Setup	Prime Video / RANDOM — Blue / Prime Video / Random		

Original		Sustituto	
TV	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
TRACKING/V-LOCK CH	CH+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	CH-	CH PAGE −	CH- / Page-
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol +	+ VOL	Vol +
INPUT SELECT AV	AV/ Input Selec	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
−	Vol -	VOL −	Vol -

Original		Sustituto	
OFF TIMER TV ASPECT	Tv Aspect	FORMAT PICTURE	Picture / Format
CANCEL/RESET A	A	NETFLIX SEARCH	Red / Netflix / Search
I-TIMER B CINEMA	B	APP REPEAT	Green / APP / Repeat
SP/LP/EP C GROUP	C	YouTube REPEAT A-B	Yellow / YouTube / Repeat
VPS/PDC D SETUP	D	Prime Video RANDOM	Blue / Prime Video / Random