Original		Sustituto	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
MEDIA PLAYER	Media Player	6	6
iPod/USB	iPod / USB	7	7
CD	CD	8	8
TUNER	Tuner	9	9
NETWORK	Network	-/-- GUIDE	Guide
TV AUDIO	TV Audio	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
FAV 1	Favorite Station	SHIFT + 1	Shift + 1
FAVORITE STATION 2	Favorite Station	SHIFT + 2	Shift + 2
TUNE - 3	Favorite Station	SHIFT + 3	Shift + 3

Original		Sustituto	
CH/PAGE ▲	CH + / Page +	+ CH	Ch +
CH/PAGE ▼	CH - / Page -	CH −	Ch -
MUTE	Mute	MUTE	Mute
VOLUME ▲	Volume +	+ VOL	Vol +
VOLUME ▼	Volume -	VOL −	Vol -
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
TUNE − ⏮	I<< / Tune -	⏮	I<<
TUNE − ⏮	I<< / Tune -	«	<<
▶/II	Play / Pause	PLAY MODE ▶	Play

Original		Sustituto	
►/II	Play / Pause	II	Pause
TUNE + ►►I	>>I / Tune +	>>I	>>I
TUNE + ►►I	>>I / Tune +	>>	>>
MOVIE	Green / Movie	B	Green
MUSIC	Red / Music	A	Red
GAME	Blue / Game	D	Blue
PURE	Yellow / Pure	C	Yellow

Original	Sustituto

Original		Sustituto	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL / SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
MEDIA PLAYER	Media Player	6	6
iPod/USB	iPod / USB	7	7
CD	CD	8	8
TUNER	Tuner	9	9
NETWORK	Network	-/-- GUIDE	Guide
TV AUDIO	TV Audio	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
FAV 1	Favorite Station	SHIFT + 1	Shift + 1
FAVORITE STATION 2	Favorite Station	SHIFT + 2	Shift + 2
TUNE - 3	Favorite Station	SHIFT + 3	Shift + 3

Original		Sustituto	
CH/PAGE ▲	CH+ / Page +	+ CH	Ch +
CH/PAGE ▼	CH - / Page -	CH −	Ch -
MUTE	Mute	MUTE	Mute
VOLUME ▲	Volume +	+ VOL	Vol +
VOLUME ▼	Volume -	VOL −	Vol -
▲	Up	▲	Up
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
TUNE − ⏮	I<< / Tune -	⏮	I<<
TUNE − ⏮	I<< / Tune -	«	<<
►/II	Play / Pause	PLAY MODE ►	Play
►/II	Play / Pause	II	Pause
TUNE + ⏭	>>I / Tune +	⏭	>>I
TUNE + ⏭	>>I / Tune +	»	>>