Original		Sustituto	
	Power		Power
TV/RAD	TV/ RAD	PROGRAM TV/RADIO	TV/ Radio /
SUBTITLE Q.MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
SUBTITLE Q.MENU	Subtitle	EQ SUBTITLE	Subtitle / EQ
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
RATIO	[ ]/Ratio	FORMAT PICTURE	Picture / Format
INPUT	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Sustituto	
LIST	List	SHIFT + LIST SMART	Shift + Smart / List
Q.VIEW	Q. View	MEDIA DISPLAY	Display / Media
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
P PAGE	P+	+ CH PAGE	CH+ / Page+
APP/*	APP/*	LANG I/II AUDIO	Audio / Lang I/II
P PAGE	P-	CH PAGE −	CH- / Page-
TEXT	[ ]/Text	GOTO TEXT	Text / Goto
INFO	Info	ANGLE INFO	Info / Angle
SMART	Smart	LIST SMART	Smart / List
MY APPS	My APPS	TITLE SOUND	Sound / Title
BACK	Back	RETURN BACK	Back / Return
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
T.OPT	T. OPT	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up

Original		Sustituto	
	Down		Down
	Right		Right
	Left		Left
	OK		OK
	Settings		Menu / Home
	*		Zoom / Size
	<<		<< / Tune-
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	>>		>> / Tune+
	Stop/Line Tv		Stop / Hold
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

Original	Sustituto