Original		Sustituto	
POWER	Power		Power
PLAY	Play	SLOW	Play / Slow
PAUSE/STEP	Pause/Step	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
BACKWARD	<<| Backward	TUNE-	<< / Tune-
FORWARD	>>| Forward	TUNE+	>> / Tune+
SKI	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
TITLE	Title	TITLE SOUND	Sound / Title
AUDIO	O))/Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	[...]/Subtitl	EQ SUBTITLE	Subtitle / EQ
EJECT OPEN/CLOSE	Eject/Open-Close	SURROUND	Eject / Surround
THUMBNAIL	Thumbnail	FORMAT PICTURE	Picture / Format
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
DUBBING	Dubbing	TIMER SLEEP	Sleep / Timer
TV/VCR	Tv/VCR	PROGRAM TV/RADIO	TV/Radio / Program

Original		Sustituto	
DISC MENU/LIST	Disc Menu/List	TOP MENU D.MENU	D.Menu / Top
I.SKIP	I.Skip	OPT-TOOLS SETUP	Setup / OPT /
CHP. ADD	CHP. ADD	GOTO TEXT	Text / Goto
AV/INPUT	AV/Input	RDS AV INPUT	AV / Input / RDS
HOME	Home	HOME MENU	Menu / Home
PR/CH(TRK)	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOL	Vol + Tv	VOL +	Vol +
PLAY MODE	Play Mode	LIST SMART	Smart / List
PR/CH(TRK)	PR/CH(TRK) +	CH+ PAGE	CH+ / Page+
	Vol - Tv	VOL -	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original	Sustituto
PR/CH(TRK) -	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
*	Guide / EPG / -/--
0	0
Marker	Fav / Marker / PC
Search	Red / Netflix / Search
Power Tv	Shift + Power
Rec Mode	Shift + Rec / Rec Mode
AV/Input Tv	Shift + AV / Input / RDS

Original	Sustituto
PR/CH+ Tv	Shift + CH+ /
PR/CH- Tv	Shift + CH- /
DVD	Shift + 2
VCR	Shift + 4