Original		Sustituto	
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
POWER	Power		Power
INFO	[≡i]/Info	ANGLE INFO	Info / Angle
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7

Original		Sustituto	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SOURCE	[≡?]/Source	SURROUND	Eject / Surround
0	0	HDMI-SAT 0	0
AUDIO	O)/I/II/Audi	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
CH+	CH+	CH PAGE +	CH+ / Page+
INDEX	Index	MEDIA DISPLAY	Display / Media
VOL+	Vol +	VOL +	Vol +
CH-	CH-	CH PAGE -	CH- / Page-
LIST	List	LIST SMART	Smart / List

Original		Sustituto		Original	Sustituto
VOL-	Vol -	VOL	Vol -		
♥	♥	PC FAV MARKER	Fav / Marker / PC		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
	Recall	RETURN BACK	Back / Return		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
	[≡]	GOTO TEXT	Text / Goto		
STILL	[≡+] / Still	SIZE ZOOM	Zoom / Size		
RADIO	Radio	PROGRAM TV/ RADIO	TV/ Radio /		
	[≡♦] / [++]	FORMAT PICTURE	Picture / Format		
	[≡x]	OPT-TOOLS SETUP	Setup / OPT /		
SUBTITLE	[≡o] / Subtitle	EQ SUBTITLE	Subtitle / EQ		
DMP	DMP	TOP MENU D.MENU	D. Menu / Top		
	Rec	REC MODE	Rec / Rec Mode		