Original	Sustituto	Original	Sustituto
Power	Power	Menu	Menu / Home
Mute	Mute / Dimmer	Up	Up
Text / Play/Paus	Play / Slow	Left	Left
Text / Play/Paus	Pause / Step / Freeze	Enter	OK
Text / Play/Paus	Text / Goto	Right	Right
Still / Stop	Stop / Hold	Down	Down
Radio	TV/Radio /	Info	Info / Angle
Aspect / Size	Zoom / Size	Exit	Exit / Cancel / Clear
Red / <<	<< / Tune-	Vol +	Vol +
Red / <<	Red / Netflix / Search	Index	Display / Media
Green / >>	Green / APP / Repeat	CH +	CH+ / Page+
Green / >>	>> / Tune+	Vol -	Vol -
Yellow / I <<	Yellow / YouTube / Repeat	List	Smart / List
Yellow / I <<	I << / Preset-	CH -	CH- / Page-
Blue / >>I	>>I / Preset+	1	1
Blue / >>I	Blue / Prime Video / Random	2	2
Source	AV / Input / RDS	3	3

Original	Sustituto	Original	Sustituto
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
Audio / I/II	Audio / Lang I/II		
0	0		
DVB	D. Menu / Top		
FAV	Fav / Marker / PC		
Sleep	Sleep / Timer		
EPG	Guide / EPG / -/--		
Prev. CH.	Back / Return		
Cancel	SHIFT + EXIT / Cancel / Clear		
Subtitle	Subtitle / EQ		
USB	SHIFT + 8 Shift + 8		
Rec	Rec / Rec Mode		