Original	Sustituto	Original	Sustituto
On Flat EQ	Audio / Lang I/II	Tuner 8	8
Preset EQ	Subtitle / EQ	Tuner 9	9
Off / On	Power	Tuner 0	0
Sleep	Sleep / Timer	CD Play	Play / Slow
Easy Play CD	Shift + 3	CD Pause	Pause / Step / Freeze
Easy Play CD	Red / Netflix / Search	CD Stop	Stop / Hold
Easy Play Tape	Green / APP / Repeat	CD I<<	I<< / Preset-
Easy Play Tape	Shift + 5	CD >>I	>>I / Preset+
Easy Play Tuner	Shift + 6	CD Program	TV/Radio /
Easy Play Tuner	Yellow / YouTube / Repeat	Turntable Play	Left
Tuner 1	1	Turntable Stop	OK
Tuner 2	2	Tape Deck 1 /	Smart / List
Tuner 3	3	Tape Pause	Shift + Pause / Step /
Tuner 4	4	Tape Play	Shift + I<< / Preset-
Tuner 5	5	Tape Stop	Shift + Stop /
Tuner 6	6	Tape Play	Shift + Play /
Tuner 7	7	Tape <<	Shift + << / Tune-

Original	Sustituto	Original	Sustituto
Tape >>	SHIFT + TUNE+ Shift + >> /		
Muting -20dB	DIMMER MUTE Mute / Dimmer		
Volume -	VOL − Vol -		
Volume +	+ VOL Vol +		

Original		Sustituto		Original	Sustituto
OFF/ON	Power Tape		Power		
TAPE	Tape	APP REPEAT	Green / APP / Repeat		
TAPE	Tape	SHIFT + TAPE 5	Shift + 5		
1	1 Tape	TV 1	1		
2	2 Tape	DVD 2	2		
3	3 Tape	CD-STB 3	3		
4	4 Tape	VIDEO 4	4		
5	5 Tape	TAPE 5	5		
6	6 Tape	TUNER 6	6		
7	7 Tape	AUX-HDD 7	7		
8	8 Tape	USB 8	8		
9	9 Tape	BLUETOOTH 9	9		
0	0 Tape	HDMI-SAT 0	0		
■	Stop Tape	HOLD ■	Stop / Hold		
▶	Play Tape	SLOW ▶	Play / Slow		
◀◀	I <</ << Tape	TUNE- ◀◀	<< / Tune-		
▶▶	>>/ >>I Tape	TUNE+ ▶▶	>> / Tune+		

Original		Sustituto		Original	Sustituto
OFF/ON	Power Tuner		Power		
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6		
TUNER	Tuner	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
1	1 Tuner	TV 1	1		
2	2 Tuner	DVD 2	2		
3	3 Tuner	CD-STB 3	3		
4	4 Tuner	VIDEO 4	4		
5	5 Tuner	TAPE 5	5		
6	6 Tuner	TUNER 6	6		
7	7 Tuner	AUX-HDD 7	7		
8	8 Tuner	USB 8	8		
9	9 Tuner	BLUETOOTH 9	9		
0	0 Tuner	HDMI-SAT 0	0		
◀◀	I <</ <<	PRESET- ⏮	I << / Preset-		
▶▶	>>/ >>I	PRESET+ ⏭	>>I / Preset+		