Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
TV/STB	TV / STB	RDS AV INPUT	AV / Input / RDS
TV/R	TV / R	PROGRAM TV/ RADIO	TV/Radio /
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SUB	SUB	EQ SUBTITLE	Subtitle / EQ
TXT	TXT	GOTO TEXT	Text / Goto
MULTI	Multi	MEDIA DISPLAY	Display / Media
P/N	P / N	FORMAT PICTURE	Picture / Format
RECALL	Recall	RETURN BACK	Back / Return
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6

Original		Sustituto	
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
SAT	SAT	SHIFT + HDMI-SAT 0	Shift + 0
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
PGUP	PGUP	CH PAGE +	CH+ / Page+
PGDN	PGDN	CH PAGE −	CH- / Page-
	Up		Up
	Right		Right
FAV+	FAV +	VOL +	Vol +
FAV-	FAV -	VOL −	Vol -
	Down		Down
	Left		Left
OK	OK	OK	OK
MENU	Menu	HOME MENU	Menu / Home

Original		Sustituto	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
EDIT	Edit	TOP MENU D.MENU	D. Menu / Top
INFO	Info	ANGLE INFO	Info / Angle
USB	USB	SHIFT + USB 8	Shift + 8
A-B	A - B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
GOTO	Goto	SHIFT + GOTO TEXT	Shift + Text /
OGG	OGG	SHIFT + TV 1	Shift + 1
JPEG	JPEG	SHIFT + DVD 2	Shift + 2
PIP	PIP	SURROUND	Eject / Surround
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode

Original		Sustituto	
T.S.	T. S.	TITLE SOUND	Sound / Title
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
PVR LIST	PVR List	LIST SMART	Smart / List
	Play / Pause	SLOW	Play / Slow
	I <<	PRESET-	I << / Preset-
	>I <	OPT-TOOLS SETUP	Setup / OPT /
	>>I	PRESET+	>>I / Preset+