Original		Sustituto	
POWER	Power		Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CH.LIST	CH. List	DISC NAV LIST	List
RECALL	Recall	FAV PRE-CH	Pre Ch
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
PIC.MODE	PIC. Mode	SHIFT + PICTURE FORMAT	Shift + Format

Original		Sustituto	
S.MODE	S. Mode	SHIFT + SOUND DUAL	Shift + Dual
SOURCE	Source	TIMER AV	AV
+ CH	CH+	+ CH	Ch +
CH −	CH-	CH −	Ch -
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok
REC	Rec	REC MODE	Rec
TIMESHIFT	Timeshift	SETTINGS OPT	Options
TIMER	Timer	SHIFT + TIMER AV	Shift + AV
REC.LIST	Rec. List	APP MEDIA	Media
	Red	A	Red
	Green	B	Green

Original		Sustituto		Original		Sustituto	
	Yellow	C	Yellow		>>		>>
	Blue	D	Blue				
ASPECT	Aspect	PICTURE FORMAT	Format				
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R				
SLEEP	Sleep	PROG SLEEP	Sleep				
SUBTITLE	Subtitle	AD SUBT	Subt				
INDEX	Index	HOME SMART	Smart				
AUDIO	Audio	SOUND DUAL	Dual				
REVEAL	Reveal	ECO 3D	3D				
DISPLAY	Display	DISPLAY INFO	Info				
TEXT	Text	REPEAT TEXT	Text				
SIZE	Play/Size	PLAY MODE	Play				
SUBPAGE	Pause/Subpage		Pause				
HOLD	Stop/Hold		Stop				
	I <<		I <<				
	>>I		>>I				
	<<		<<				