Original		Sustituto	
STANDBY	Standby		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
INFO	Info	ANGLE INFO	Info / Angle
0	0	HDMI - SAT 0	0
RECALL	Recall	RETURN BACK	Back / Return
TV/RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/Radio / Program

Original		Sustituto	
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
OK	OK	OK	OK
	Right		Right
RECORD	Record	REC MODE	Rec / Rec Mode
	Down		Down
STOP	Stop	HOLD	Stop / Hold
+ VOL	Vol +	+ VOL	Vol +
+ CH	CH +	+ CH PAGE	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
TTX	TTX	GOTO TEXT	Text / Goto
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
CH -	CH -	CH PAGE -	CH- / Page-
MEDIA	Media	MEDIA DISPLAY	Display / Media
PREV	I<< Prev	PRESET-	I<< / Preset-

Original		Sustituto		Original	Sustituto
PLAY	Play	SLOW	Play / Slow		
REV	<< REV	TUNE-	<< / Tune-		
USB	USB	SHIFT + USB 8	Shift + 8		
NEXT	Next >>I	PRESET+	>>I / Preset+		
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze		
FWD	FWD >>	TUNE+	>> / Tune+		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		