Mandis shop

Sharp RRMCGA177AWSA

Original		Sustituto	
ON/ STAND-BY	On/ Standby		Power
STANDARD	Standard	A	Red
CINEMA/GAME	Cinema/ Game	B	Green
SPORT	Sport	C	Yellow
NEWS	News	D	Blue
VOLUME +	Vol +	VOL +	Vol +
VOLUME −	Vol -	VOL −	Vol -
SUBWOOFER LEVEL ^	Subwoofer Level		Up
SUBWOOFER LEVEL v	Subwoofer Level Down		Down
MUTE	Mute	MUTE	Mute
BASS/ TREBLE	Bass/ Treble	SOUND DUAL	Dual
DIMMER	Dimmer	APP MEDIA	Media
LINE	Line	HOME SMART	Smart
ON/ STAND-BY	On/ Standby Tv	SHIFT +	Shift + Power
INPUT	Input Tv	TIMER AV	AV
CHANNEL ^	CH+ Tv	CH +	Ch +
CHANNEL v	CH- Tv	CH −	Ch -

Original		Sustituto	
VOLUME +	Vol + Tv	SHIFT + VOL +	Shift + Vol +
VOLUME −	Vol - Tv	SHIFT + VOL −	Shift + Vol -

https://mandis.es/es/Sharp/1325-888-mando-sustituto-para-Sharp-Sound-Bar-System-RRMCGA177AWSA.html